


Circuit protection devices 2005 - 2006

hager group



Welcome to the new edition of our general catalogue

For easy reference purposes, Hager general catalogue has been divided into three separate catalogues each representing the following product groups :

1. Enclosures and Connection Systems
2. Circuit Protection Devices
3. Modular Automation and Control Devices

A technical section, at the end of each catalogue provides detailed information of the products and its applications.

The logo for Hager, consisting of the word "hager" in a lowercase, blue, sans-serif font.

The success is in the system

the Hager Group

With more than 7500 employees worldwide and a line of innovative products, the Hager Group is one of the leading manufacturers of electrical equipment for homes, business premises and office buildings.

Our mission

Our primary mission is to contribute to a safe and efficient distribution of electrical energy and actively participate in the improvement of building comfort.

In line with this mission statement, our ambition is to offer the market a complete range of products and services needed for the design and the implementation of a fully integrated electrical installation in homes, business premises and office buildings.

Despite its growth in recent years, the Hager Group today remains essentially a family and independent Group of companies, with its founders still managing the business with the help of the Executive Team.



A global company

The expansion of the Hager Group worldwide was not solely limited to creating commercial agencies, but included the set up of a global industrial organisation with full design and production capabilities to offer the various markets suitable products.

Today the Hager Group is present in 60 countries with more than 2300 points of sale and offers various products and systems meeting very different needs.

Quality and Human Resources

Although Hager's success was based on the relevance of its offer and the performance of its industrial organization, Human Resources are its basic and fundamental assets. Hager's renowned quality for products, services and sales organisation

was made possible by the use of advanced equipment and a Quality Assurance System registered to ISO 9001. But it was made possible first and foremost by the involvement of the highly qualified men and women of the Company using such equipment and implementing such Quality Organisation.



Obernai - France



Tehalit headquarters in Heltersberg - Germany



Telford - UK



Ensheim - Germany

Hager product brands



hager

Hager products form a fully integrated system for safe, efficient and effective protection and control of electrical distribution systems.

- Consumer units system.
- Distribution board system.
- Enclosures.
- Busbars and connections.
- Protection devices.
- Modular control devices.
- Intelligent installation system for control of lighting, heating and shutters.
- Wiring accessories.



TEHALIT

Tehalit products cover the complete spectrum of cable management and include systems for domestic, commercial and industrial applications.

- Skirting systems.
- Multi - compartment dado systems.
- Architectural systems.
- Island systems.
- Industrial trunking systems.
- Panel trunkings.
- Fire resistant trunkings.



klik

KLIK secure connection systems provide an innovative solution to a variety of connection requirements. Systems are available for power and lighting distribution applications.

- KLIK lighting
- KLIK AX
- KLIK Power
- KLIK LV.
- Lighting distribution systems.
- Occupancy sensors.

Numerical index

| Cat.ref. Page No. |
|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| A | | | | | |
| AD106Z 26 | AF125Z 26 | BF484 18 | CF264Z 23 | L147 19 | MB206A 10 |
| AD110Z 26 | AF132Z 26 | BF485 18 | CF281Z 23 | L304 19 | MB210A 10 |
| AD116Z 26 | AF140Z 26 | BN264 15 | CF285Z 23 | L305 19 | MB216A 10 |
| AD120Z 26 | AF956B 25 | BN464 15 | CF425J 23 | L306 19 | MB220A 10 |
| AD125Z 26 | AF956J 25 | BP264 15 | CF426Z 23 | L307 19 | MB225A 10 |
| AD127 26 | AF960B 25 | BP285 18 | CF440J 23 | L308 19 | MB232A 10 |
| AD128 26 | AF960J 25 | BP364 15 | CF441J 23 | L324 19 | MB240A 10 |
| AD132Z 26 | AF966B 25 | BP385 18 | CF441Z 23 | L325 19 | MB250A 10 |
| AD140Z 26 | AF966J 25 | BP464 15 | CF426J 23 | L326 19 | MB263A 10 |
| AD184 26 | AF970B 25 | BP485 18 | CF463J 23 | L327 19 | MB306A 10 |
| AD185 26 | AF970J 25 | BS264 15 | CF464J 23 | L328 19 | MB310A 10 |
| AD187 26 | AF975B 25 | BS364 15 | CF464Z 23 | L401 20 | MB316A 10 |
| AD188 26 | AF975J 25 | BS464 15 | CF481Z 23 | L402 20 | MB320A 10 |
| AD189 26 | AF982B 25 | | CF485Z 23 | L403 20 | MB325A 10 |
| AD190 26 | AF982J 25 | C | CG481Z 23 | L404 20 | MB332A 10 |
| AD191 26 | AF990B 25 | CC217J 23 | CG485Z 23 | L406 20 | MB340A 10 |
| AD806J 25 | AF990J 25 | CC217Z 23 | CP265F 23 | L412 20 | MB350A 10 |
| AD810J 25 | AN150Z 26 | CD225J 23 | CP441J 23 | L431 20 | MB363A 10 |
| AD816J 25 | AP150Z 26 | CD226J 23 | CP445F 23 | L432 20 | MB406A 10 |
| AD820J 25 | | CD226Z 23 | CP464J 23 | L501 20 | MB410A 10 |
| AD825J 25 | B | CD227T 23 | CP465F 23 | L502 20 | MB416A 10 |
| AD832J 25 | BC226 15 | CD240J 23 | CZ001 24 | L503 20 | MB420A 10 |
| AD840J 25 | BD225 16 | CD241J 23 | CZ005 24 | L504 20 | MB425A 10 |
| AD856J 25 | BD226 15 | CD241Z 23 | CZ006 24 | L506 20 | MB432A 10 |
| AD860J 25 | BD240 16 | CD242T 23 | CZ007 24 | L512 20 | MB440A 10 |
| AD866J 25 | BD241 15 | CD263J 23 | CZ008 24 | L531 20 | MB450A 10 |
| AD870J 25 | BD263 16 | CD264J 23 | CZN005 24 | L532 20 | MB463A 10 |
| AD875J 25 | BD264 15 | CD264Z 23 | CZN006 24 | LF138 19 | MC100A 10 |
| AD882J 25 | BD284 18 | CD265T 23 | | LF139 19 | MC101A 10 |
| AD890J 25 | BD285 18 | CD281Z 23 | H | LF140 19 | MC102A 10 |
| AD906B 25 | BD325 16 | CD285Z 23 | HR400 27 | LF141 19 | MC103A 10 |
| AD906J 25 | BD326 15 | CD425J 23 | HR402 27 | LF142 19 | MC104A 10 |
| AD910B 25 | BD340 16 | CD426J 23 | HR410 27 | LR601 21 | MC106A 10 |
| AD910J 25 | BD341 15 | CD426Z 23 | HR420 27 | LR602 21 | MC110A 10 |
| AD910J 25 | BD363 16 | CD427T 23 | HR425 27 | LR603 21 | MC116A 10 |
| AD910J 25 | BD364 15 | CD440J 23 | HR800 28 | LR604 21 | MC120A 10 |
| AD916B 25 | BD384 18 | CD441J 23 | HR801 28 | LR612 21 | MC125A 10 |
| AD916J 25 | BD385 18 | CD441Z 23 | HR802 28 | LR701 22 | MC132A 10 |
| AD920B 25 | BD425 16 | CD442T 23 | HR803 28 | LR702 22 | MC140A 10 |
| AD920J 25 | BD426 15 | CD463J 23 | HR804 28 | LR703 22 | MC150A 10 |
| AD920J 25 | BD441 15 | CD464J 23 | HR805 28 | LR704 22 | MC163A 10 |
| AD925B 25 | BD463 16 | CD464Z 23 | HR820 28 | LR712 22 | MC200A 10 |
| AD925J 25 | BD464 15 | CD465T 23 | HR821 28 | LS601 21 | MC201A 10 |
| AD932B 25 | BD484 18 | CD480Z 23 | HR822 28 | LS602 21 | MC202A 10 |
| AD932J 25 | BD485 18 | CD485Z 23 | HR823 28 | LS603 21 | MC203A 10 |
| AD940B 25 | BE264 15 | CE226J 23 | HR824 28 | LS604 21 | MC204A 10 |
| AD940J 25 | BE464 15 | CE226Z 23 | HR830 28 | LS612 21 | MC206A 10 |
| AD956B 25 | BF225 16 | CE241J 23 | HR831 28 | LS670 21 | MC210A 10 |
| AD956J 25 | BF226 15 | CE241Z 23 | HR832 28 | LS671 21 | MC216A 10 |
| AD960B 25 | BF240 16 | CE264J 23 | | LS672 21 | MC220A 10 |
| AD960J 25 | BF241 15 | CE264Z 23 | L | LS672 22 | MC225A 10 |
| AD966B 25 | BF263 16 | CE281Z 23 | L022 20 | LS701 22 | MC232A 10 |
| AD966J 25 | BF264 15 | CE285Z 23 | L023 20 | LS702 22 | MC240A 10 |
| AD970B 25 | BF284 18 | CE426J 23 | L024 20 | LS703 22 | MC250A 10 |
| AD970J 25 | BF285 18 | CE426Z 23 | L025 20 | LS704 22 | MC263A 10 |
| AD975B 25 | BF325 16 | CE441J 23 | L053 20 | LS712 22 | MC300A 10 |
| AD975J 25 | BF326 15 | CE441Z 23 | L055 20 | LS770 22 | MC301A 10 |
| AD982B 25 | BF340 16 | CE464J 23 | L065 22 | LS771 22 | MC302A 10 |
| AD982J 25 | BF341 15 | CE464Z 23 | L104 19 | | MC303A 10 |
| AD990B 25 | BF363 16 | CE481Z 23 | L105 19 | M | MC304A 10 |
| AD990J 25 | BF364 15 | CE485Z 23 | L106 19 | MB106A 10 | MC306A 10 |
| AE106Z 26 | BF384 18 | CF225J 23 | L107 19 | MB110A 10 | MC310A 10 |
| AE110Z 26 | BF385 18 | CF225U 23 | L108 19 | MB116A 10 | MC316A 10 |
| AE116Z 26 | BF425 16 | CF226J 23 | L109 19 | MB120A 10 | MC320A 10 |
| AE120Z 26 | BF426 15 | CF240J 23 | L124 19 | MB125A 10 | MC325A 10 |
| AE125Z 26 | BF440 16 | CF241J 23 | L125 19 | MB132A 10 | MC332A 10 |
| AE132Z 26 | BF441 15 | CF241Z 23 | L126 19 | MB140A 10 | MC340A 10 |
| AE140Z 26 | BF463 16 | CF263J 23 | L127 19 | MB150A 10 | MC350A 10 |
| AF120Z 26 | BF464 15 | CF264J 23 | L128 19 | MB163A 10 | MC363A 10 |

Numerical index


Cat.ref.	Page No.										
MC406A	10	MU132A	9	MW220	8	NC303A	11	ND350A	11	NR325A	12
MC410A	10	MU140A	9	MW225	8	NC304A	11	ND363A	11	NR332A	12
MC416A	10	MU150A	9	MW232	8	NC306A	11	ND380	17	NR340A	12
MC420A	10	MU163A	9	MW240	8	NC310A	11	ND384	17	NR350A	12
MC425A	10	MU206A	9	MW306	8	NC316A	11	ND400A	11	NR363A	12
MC432A	10	MU210A	9	MW310	8	NC320A	11	ND401A	11	NR400A	12
MC440A	10	MU216A	9	MW316	8	NC325A	11	ND402A	11	NR401A	12
MC450A	10	MU220A	9	MW320	8	NC332A	11	ND403A	11	NR402A	12
MC463A	10	MU225A	9	MW325	8	NC340A	11	ND404A	11	NR403A	12
MJ702	13	MU232A	9	MW332	8	NC350A	11	ND406A	11	NR404A	12
MJ706	13	MU240A	9	MW340	8	NC363A	11	ND410A	11	NR406A	12
MJ710	13	MU250A	9	MW406	8	NC400A	11	ND416A	11	NR410A	12
MJ716	13	MU263A	9	MW410	8	NC401A	11	ND420A	11	NR416A	12
MJ720	13	MU306A	9	MW416	8	NC402A	11	ND425A	11	NR420A	12
MJ725	13	MU310A	9	MW420	8	NC403A	11	ND432A	11	NR425A	12
MJ732	13	MU316A	9	MW425	8	NC404A	11	ND440A	11	NR432A	12
MJ740	13	MU320A	9	MW432	8	NC406A	11	ND450A	11	NR440A	12
ML706	13	MU325A	9	MW440	8	NC410A	11	ND463A	11	NR450A	12
ML710	13	MU332A	9	MZ176	14	NC416A	11	ND480	17	NR463A	12
ML716	13	MU340A	9	MZ201	14	NC420A	11	ND484	17		
ML720	13	MU350A	9	MZ202	14	NC425A	11	NM180	17	S	
ML725	13	MU363A	9	MZ203	14	NC432A	11	NM184	17	SB116	29
ML732	13	MU406A	9	MZ204	14	NC440A	11	NM190	17	SB125	29
ML740	13	MU410A	9	MZ205	14	NC450A	11	NM280	17	SB125V	29
MM501N	34	MU416A	9	MZ206	14	NC463A	11	NM284	17	SB132	29
MM502N	34	MU420A	9	MZ520N	35	ND100A	11	NM290	17	SB132V	29
MM503N	34	MU425A	9	MZ521N	35	ND101A	11	NM380	17	SB140	29
MM504N	34	MU432A	9	MZ522N	35	ND102A	11	NM384	17	SB163	29
MM505N	34	MU440A	9	MZ523N	35	ND103A	11	NM390	17	SB180	29
MM506N	34	MU450A	9	MZ527N	35	ND104A	11	NM480	17	SB199	29
MM507N	34	MU463A	9	MZ528N	35	ND106A	11	NM484	17	SB216	29
MM508N	34	MV106	8	MZ529N	35	ND110A	11	NM490	17	SB216V	29
MM509N	34	MV110	8	MZ530N	35	ND116A	11	NR100A	12	SB225	29
MM510N	34	MV116	8	MZ531N	35	ND120A	11	NR101A	12	SB225V	29
MM511N	34	MV120	8	MZN175	14	ND125A	11	NR102A	12	SB232	29
MM512N	34	MV125	8	MZN176	14	ND132A	11	NR103A	12	SB232V	29
MM513N	34	MV132	8			ND140A	11	NR104A	12	SB240	29
MT106A	9	MV140	8	N		ND150A	11	NR106A	12	SB263	29
MT110A	9	MV206	8	NC100A	11	ND163A	11	NR110A	12	SB280	29
MT116A	9	MV210	8	NC101A	11	ND180	17	NR116A	12	SB299	29
MT120A	9	MV216	8	NC102A	11	ND184	17	NR120A	12	SB316	29
MT125A	9	MV220	8	NC103A	11	ND200A	11	NR125A	12	SB325	29
MT132A	9	MV225	8	NC104A	11	ND201A	11	NR132A	12	SB332	29
MT140A	9	MV232	8	NC106A	11	ND202A	11	NR140A	12	SB332Q	29
MT150A	9	MV240	8	NC110A	11	ND203A	11	NR150A	12	SB340	29
MT163A	9	MV306	8	NC116A	11	ND204A	11	NR163A	12	SB363	29
MT206A	9	MV310	8	NC120A	11	ND206A	11	NR200A	12	SB380	29
MT210A	9	MV316	8	NC125A	11	ND210A	11	NR201A	12	SB399	29
MT216A	9	MV320	8	NC132A	11	ND216A	11	NR202A	12	SB416	29
MT220A	9	MV325	8	NC140A	11	ND220A	11	NR203A	12	SB416F	29
MT225A	9	MV332	8	NC150A	11	ND225A	11	NR204A	12	SB425	29
MT232A	9	MV340	8	NC163A	11	ND232A	11	NR206A	12	SB425F	29
MT240A	9	MV406	8	NC200A	11	ND240A	11	NR210A	12	SB432	29
MT250A	9	MV410	8	NC201A	11	ND250A	11	NR216A	12	SB432F	29
MT263A	9	MV416	8	NC202A	11	ND263A	11	NR220A	12	SB440	29
MT306A	9	MV420	8	NC203A	11	ND280	17	NR225A	12	SB440F	29
MT310A	9	MV425	8	NC204A	11	ND284	17	NR232A	12	SB463	29
MT316A	9	MV432	8	NC206A	11	ND300A	11	NR240A	12	SB463F	29
MT320A	9	MV440	8	NC210A	11	ND301A	11	NR250A	12	SB480	29
MT325A	9	MW106	8	NC216A	11	ND302A	11	NR263A	12	SB480F	29
MT332A	9	MW110	8	NC220A	11	ND303A	11	NR300A	12	SB499	29
MT340A	9	MW116	8	NC225A	11	ND304A	11	NR301A	12	SB499F	29
MT350A	9	MW120	8	NC232A	11	ND306A	11	NR302A	12	SF115	30
MT363A	9	MW125	8	NC240A	11	ND310A	11	NR303A	12	SF118F	30
MU106A	9	MW132	8	NC250A	11	ND316A	11	NR304A	12	SF119F	30
MU110A	9	MW140	8	NC263A	11	ND320A	11	NR306A	12	SF119G	30
MU116A	9	MW206	8	NC300A	11	ND325A	11	NR310A	12	SF218F	30
MU120A	9	MW210	8	NC301A	11	ND332A	11	NR316A	12	SF219F	30
MU125A	9	MW216	8	NC302A	11	ND340A	11	NR320A	12	SF219G	30

Numerical index


| Cat.ref. Page No. |
|-------------------|-------------------|-------------------|-------------------|-------------------|-------------------|
| SF319G | 30 | | | | |
| SF419G | 30 | | | | |
| SPA212A | 31 | | | | |
| SPA412A | 31 | | | | |
| SPN015D | 32 | | | | |
| SPN015R | 32 | | | | |
| SPN040C | 32 | | | | |
| SPN040D | 32 | | | | |
| SPN040N | 32 | | | | |
| SPN040R | 32 | | | | |
| SPN065N | 32 | | | | |
| SPN065R | 32 | | | | |
| SPN140C | 32 | | | | |
| SPN208S | 33 | | | | |
| SPN215D | 32 | | | | |
| SPN215R | 32 | | | | |
| SPN240D | 32 | | | | |
| SPN240R | 32 | | | | |
| SPN265R | 31 | | | | |
| SPN408S | 33 | | | | |
| SPN415D | 32 | | | | |
| SPN415R | 32 | | | | |
| SPN440D | 32 | | | | |
| SPN440R | 32 | | | | |
| SPN465R | 31 | | | | |
| SPN504 | 33 | | | | |
| SPN505 | 33 | | | | |
| SZ011 | 30 | | | | |

Protection devices

- 8 Miniature circuit breakers - MV, MW, MT, MU
- 10 Miniature circuit breakers - MB, MC
- 11 Miniature circuit breakers - NC, ND
- 12 Miniature circuit breakers - NR
- 13 Miniature circuit breakers - MJ, ML
- 14 Auxiliaries and accessories for devices
- 15 RCCB add on blocks
- 17 Miniature circuit breakers- NM, ND
80, 100 and 125A
- 18 RCCB add on blocks - type AC/A
- 19 HRC fuse carrier range - LB, LBX, L and LX
- 20 HRC fuse carrier range - L31, L38, L51, L58
- 23 RCCBs 2 and 4 poles
- 25 RCBOs (residual circuit breaker with overload)
- 27 Earth leakage relays
- 29 Isolating switches
- 30 2 way/centre-off changeover modular switches
- 31 Surge protective devices
- 34 Motors starters



Miniature circuit breakers 3kA Type B and C - MV, MW



Description

Protection and control of circuits against overloads and short circuits.

Technical data

Type B and C tripping characteristics
Tropicalisation T2
Breaking capacity : 3000A to IEC898
Voltage rating : 230-400 V
Current rating : 6-40A
IP2X

Connection capacity

25□ rigid cables
16□ flexible cables

- will not accept accessories

Voltage marking as per IEC38
can be used on 240/415V
50Hz without derating

□ For technical details see pages 40-43

Designation	In/A	Width in 17.5mm	Pack qty.	B curve cat. ref.	C curve cat. ref.
-------------	------	-----------------	-----------	-------------------	-------------------



MW 110

Single pole MCB



6	1	12	MV 106	MW 106
10	1	12	MV 110	MW 110
16	1	12	MV 116	MW 116
20	1	12	MV 120	MW 120
25	1	12	MV 125	MW 125
32	1	12	MV 132	MW 132
40	1	12	MV 140	MW 140

Double pole MCB



6	2	6	MV 206	MW 206
10	2	6	MV 210	MW 210
16	2	6	MV 216	MW 216
20	2	6	MV 220	MW 220
25	2	6	MV 225	MW 225
32	2	6	MV 232	MW 232
40	2	6	MV 240	MW 240



MW 220

Triple pole MCB



6	3	4	MV 306	MW 306
10	3	4	MV 310	MW 310
16	3	4	MV 316	MW 316
20	3	4	MV 320	MW 320
25	3	4	MV 325	MW 325
32	3	4	MV 332	MW 332
40	3	4	MV 340	MW 340

Four pole MCB




6	4	3	MV 406	MW 406
10	4	3	MV 410	MW 410
16	4	3	MV 416	MW 416
20	4	3	MV 420	MW 420
25	4	3	MV 425	MW 425
32	4	3	MV 432	MW 432
40	4	3	MV 440	MW 440



MW 316

Miniature circuit breakers 6kA Type B and C - MT, MU



Description
Protection and control of circuits against overloads and short circuits.

Technical data
Type B and C tripping characteristics
Tropicalisation T2
Breaking capacity :
6000A to IEC898
10000A to IEC947-2
Voltage rating : 230-400 V
Current rating : 6-63A
IP2X

Connection capacity

25□ rigid cables
16□ flexible cables

- will not accept accessories

Voltage marking as per IEC38
can be used on 240/415V
50Hz without derating

□ For technical details
see pages 40-43

Designation	In/A	Width in 17.5mm	Pack qty.	B curve cat. ref.	C curve cat. ref.
Single pole MCB					
	6	1	12	MT 106A	MU 106A
	10	1	12	MT 110A	MU 110A
	16	1	12	MT 116A	MU 116A
	20	1	12	MT 120A	MU 120A
	25	1	12	MT 125A	MU 125A
	32	1	12	MT 132A	MU 132A
	40	1	12	MT 140A	MU 140A
	50	1	12	MT 150A	MU 150A
	63	1	12	MT 163A	MU 163A
	Double pole MCB				
	6	2	6	MT 206A	MU 206A
	10	2	6	MT 210A	MU 210A
	16	2	6	MT 216A	MU 216A
	20	2	6	MT 220A	MU 220A
	25	2	6	MT 225A	MU 225A
	32	2	6	MT 232A	MU 232A
	40	2	6	MT 240A	MU 240A
	50	2	6	MT 250A	MU 250A
	63	2	6	MT 263A	MU 263A
	Triple pole MCB				
	6	3	4	MT 306A	MU 306A
	10	3	4	MT 310A	MU 310A
	16	3	4	MT 316A	MU 316A
	20	3	4	MT 320A	MU 320A
	25	3	4	MT 325A	MU 325A
	32	3	4	MT 332A	MU 332A
	40	3	4	MT 340A	MU 340A
	50	3	4	MT 350A	MU 350A
	63	3	4	MT 363A	MU 363A
Four pole MCB					
	6	4	3		MU 406A
	10	4	3		MU 410A
	16	4	3		MU 416A
	20	4	3		MU 420A
	25	4	3		MU 425A
	32	4	3		MU 432A
	40	4	3		MU 440A
	50	4	3		MU 450A
63	4	3		MU 463A	



MT 116A




MT 216A



MT 320A

Miniature circuit breakers 6kA Type B and C - MB, MC



Description
Protection and control of circuits against overloads and short circuits.

Technical data
Type B and C tripping characteristics
Tropicalisation T2
Breaking capacity : 6000A to IEC898

10000A to IEC947-2
Voltage rating : 230-400 V
Current rating : 0.5 - 63A
IP2X

Connection capacity
25□ rigid cables
16□ flexible cables

- will accept accessories
see page 14

Voltage marking as per IEC38 can be used on 240/415V 50Hz without derating

□ For technical details see pages 40-43

Designation	In/A	Width in I 17.5mm	Pack qty.	B curve cat. ref.	C curve cat. ref.
Single pole MCB					
	0.5	1	12		MC 100A
	1	1	12		MC 101A
	2	1	12		MC 102A
	3	1	12		MC 103A
	4	1	12		MC 104A
	6	1	12	MB 106A	MC 106A
	10	1	12	MB 110A	MC 110A
	16	1	12	MB 116A	MC 116A
	20	1	12	MB 120A	MC 120A
	25	1	12	MB 125A	MC 125A
	32	1	12	MB 132A	MC 132A
	40	1	12	MB 140A	MC 140A
	50	1	12	MB 150A	MC 150A
63	1	12	MB 163A	MC 163A	
Double pole MCB					
	0.5	2	6		MC 200A
	1	2	6		MC 201A
	2	2	6		MC 202A
	3	2	6		MC 203A
	4	2	6		MC 204A
	6	2	6	MB 206A	MC 206A
	10	2	6	MB 210A	MC 210A
	16	2	6	MB 216A	MC 216A
	20	2	6	MB 220A	MC 220A
	25	2	6	MB 225A	MC 225A
	32	2	6	MB 232A	MC 232A
	40	2	6	MB 240A	MC 240A
	50	2	6	MB 250A	MC 250A
63	2	6	MB 263A	MC 263A	
Triple pole MCB					
	0.5	3	4		MC 300A
	1	3	4		MC 301A
	2	3	4		MC 302A
	3	3	4		MC 303A
	4	3	4		MC 304A
	6	3	4	MB 306A	MC 306A
	10	3	4	MB 310A	MC 310A
	16	3	4	MB 316A	MC 316A
	20	3	4	MB 320A	MC 320A
	25	3	4	MB 325A	MC 325A
	32	3	4	MB 332A	MC 332A
	40	3	4	MB 340A	MC 340A
	50	3	4	MB 350A	MC 350A
63	3	4	MB 363A	MC 363A	
Four pole MCB					
	6	4	3	MB 406A	MC 406A
	10	4	3	MB 410A	MC 410A
	16	4	3	MB 416A	MC 416A
	20	4	3	MB 420A	MC 420A
	25	4	3	MB 425A	MC 425A
	32	4	3	MB 432A	MC 432A
	40	4	3	MB 440A	MC 440A
	50	4	3	MB 450A	MC 450A
	63	4	3	MB 463A	MC 463A



MC 132A



MC 216A




MC 332A



MC 432A

Miniature circuit breakers 10kA Type C and D - NC, ND



Description
Protection and control of circuits against overloads and short circuits.

Technical data
Type C and D tripping characteristics
Tropicalisation T2

Breaking capacity :
10000A to IEC898
15000A to IEC947-2
Voltage rating : 230-400 V
Current rating : 0.5 - 63A

Positive contact indication :
red - contacts closed
green - contacts open
- **will accept accessories**
see page 14

Connection capacity
25□ rigid cables
16□ flexible cables

Voltage marking as per IEC38
can be used on 240/415V
50Hz without derating

□ For technical details
see pages 40-43

Designation	In/A	Width in 17.5mm	Pack qty.	C curve cat. ref.	D curve cat. ref.
-------------	------	-----------------	-----------	-------------------	-------------------



NC 116A

Single pole MCB



0.5	1	12	NC 100A	ND 100A
1	1	12	NC 101A	ND 101A
2	1	12	NC 102A	ND 102A
3	1	12	NC 103A	ND 103A
4	1	12	NC 104A	ND 104A
6	1	12	NC 106A	ND 106A
10	1	12	NC 110A	ND 110A
16	1	12	NC 116A	ND 116A
20	1	12	NC 120A	ND 120A
25	1	12	NC 125A	ND 125A
32	1	12	NC 132A	ND 132A
40	1	12	NC 140A	ND 140A
50	1	12	NC 150A	ND 150A
63	1	12	NC 163A	ND 163A



NC 232A

Double pole MCB




0.5	2	6	NC 200A	ND 200A
1	2	6	NC 201A	ND 201A
2	2	6	NC 202A	ND 202A
3	2	6	NC 203A	ND 203A
4	2	6	NC 204A	ND 204A
6	2	6	NC 206A	ND 206A
10	2	6	NC 210A	ND 210A
16	2	6	NC 216A	ND 216A
20	2	6	NC 220A	ND 220A
25	2	6	NC 225A	ND 225A
32	2	6	NC 232A	ND 232A
40	2	6	NC 240A	ND 240A
50	2	6	NC 250A	ND 250A
63	2	6	NC 263A	ND 263A



NC 363A

Triple pole MCB




0.5	3	4	NC 300A	ND 300A
1	3	4	NC 301A	ND 301A
2	3	4	NC 302A	ND 302A
3	3	4	NC 303A	ND 303A
4	3	4	NC 304A	ND 304A
6	3	4	NC 306A	ND 306A
10	3	4	NC 310A	ND 310A
16	3	4	NC 316A	ND 316A
20	3	4	NC 320A	ND 320A
25	3	4	NC 325A	ND 325A
32	3	4	NC 332A	ND 332A
40	3	4	NC 340A	ND 340A
50	3	4	NC 350A	ND 350A
63	3	4	NC 363A	ND 363A




NC 463A

Four pole MCB



0.5	4	3	NC 400A	ND 400A
1	4	3	NC 401A	ND 401A
2	4	3	NC 402A	ND 402A
3	4	3	NC 403A	ND 403A
4	4	3	NC 404A	ND 404A
6	4	3	NC 406A	ND 406A
10	4	3	NC 410A	ND 410A
16	4	3	NC 416A	ND 416A
20	4	3	NC 420A	ND 420A
25	4	3	NC 425A	ND 425A
32	4	3	NC 432A	ND 432A
40	4	3	NC 440A	ND 440A
50	4	3	NC 450A	ND 450A
63	4	3	NC 463A	ND 463A

Miniature circuit breakers 15 to 25 kA Type C - NR



Description
Protection and control of circuits against overloads and short circuits.

Technical data
Type C tripping characteristics
Tropicalisation T2
Breaking capacity :
25000A (≤ 20A)
20000A (25 to 40A)

15000A (50 - 63A)
to IEC947-2
Voltage rating : 230-400 V
Current rating : 0.5 - 63A
Positive contact indication :
red - contacts closed
green - contacts open

- will accept accessories
see page 14

Voltage marking as per IEC38
can be used on 240/415V
50Hz without derating

Connection capacity
25□ rigid cables
16□ flexible cables

□ For technical details
see pages 40-43

Designation	Breaking capacity kA	In/A	Width in 17.5mm	Pack qty.	Cat. ref.
-------------	----------------------	------	-----------------	-----------	-----------

Single pole MCB



NR 116A

25	0,5	1	1	12	NR 100A
25	1	1	1	12	NR 101A
25	2	1	1	12	NR 102A
25	3	1	1	12	NR 103A
25	4	1	1	12	NR 104A
25	6	1	1	12	NR 106A
25	10	1	1	12	NR 110A
25	16	1	1	12	NR 116A
25	20	1	1	12	NR 120A
20	25	1	1	12	NR 125A
20	32	1	1	12	NR 132A
20	40	1	1	12	NR 140A
15	50	1	1	12	NR 150A
15	63	1	1	12	NR 163A


Double pole MCB



NR 232A

25	0,5	2	6	6	NR 200A
25	1	2	6	6	NR 201A
25	2	2	6	6	NR 202A
25	3	2	6	6	NR 203A
25	4	2	6	6	NR 204A
25	6	2	6	6	NR 206A
25	10	2	6	6	NR 210A
25	16	2	6	6	NR 216A
25	20	2	6	6	NR 220A
20	25	2	6	6	NR 225A
20	32	2	6	6	NR 232A
20	40	2	6	6	NR 240A
15	50	2	6	6	NR 250A
15	63	2	6	6	NR 263A


Triple pole MCB



NR 340A

25	0,5	3	4	4	NR 300A
25	1	3	4	4	NR 301A
25	2	3	4	4	NR 302A
25	3	3	4	4	NR 303A
25	4	3	4	4	NR 304A
25	6	3	4	4	NR 306A
25	10	3	4	4	NR 310A
25	16	3	4	4	NR 316A
25	20	3	4	4	NR 320A
20	25	3	4	4	NR 325A
20	32	3	4	4	NR 332A
20	40	3	4	4	NR 340A
15	50	3	4	4	NR 350A
15	63	3	4	4	NR 363A


Four pole MCB



NR 440A

25	0,5	4	3	3	NR 400A
25	1	4	3	3	NR 401A
25	2	4	3	3	NR 402A
25	3	4	3	3	NR 403A
25	4	4	3	3	NR 404A
25	6	4	3	3	NR 406A
25	10	4	3	3	NR 410A
25	16	4	3	3	NR 416A
25	20	4	3	3	NR 420A
20	25	4	3	3	NR 425A
20	32	4	3	3	NR 432A
20	40	4	3	3	NR 440A
15	50	4	3	3	NR 450A
15	63	4	3	3	NR 463A

Miniature circuit breakers 4,5 - 6kA Type C SP&N - MJ and ML



Description
Protection and control of circuits against overloads and short circuits.

Technical data
Type C tripping characteristics
Tropicalisation T2
Breaking capacity :
4 500A, 6 000A to IEC898
Voltage rating : 230V
Current rating : 2-40A
IP2X

Connection capacity
16□ rigid cables
10□ flexible cables
+ busbars

Voltage marking as per IEC38
can be used on 240/415V
50Hz without derating

□ For technical details
see pages 40-43



MJ 716

Designation	In/A	Width in 17.5mm	Pack qty.	Cat. ref.
Single pole and switched neutral - 4,5kA	2	1	12	MJ 702
	6	1	12	MJ 706
SP&N	10	1	12	MJ 710
	16	1	12	MJ 716
	20	1	12	MJ 720
	25	1	12	MJ 725
	32	1	12	MJ 732
	40	1	12	MJ 740



ML 716

Single pole and switched neutral - 6kA	6	1	12	ML 706
	10	1	12	ML 710
SP&N	16	1	12	ML 716
	20	1	12	ML 720
	25	1	12	ML 725
	32	1	12	ML 732
	40	1	12	ML 740

Auxiliaries and accessories for devices MB, MC, NC, ND, NR MCBs and RCCBs

All auxiliaries are common to both single and multi-pole circuit breakers. These auxiliaries are fitted to the left hand side of devices.

Shunt trips, and under-voltage releases are fitted with a reset button that indicates the automatic/remote tripping of the device.

Connection capacity
6□ rigid cables
4□ flexible cables

For fitting to RCCB
- see page 45

Use of MZ 203 - MZ 206 on RCCBs requires the use of interface auxiliary CZ 001

□ For technical details see page 44

Designation	Description	Width in I 17.5mm	Pack qty.	Cat. ref.
Auxiliary contacts 5A - 230V~ 	1NO + 1NC auxiliary contact indication of main contact status.	1/2	1	MZ 201
Alarm contacts condition (e.g. MCB tripped) 	SD contact indicates a fault overcurrent (e.g. MCB tripped) on overload or short circuit).	1/2	1	MZ 202
Shunt trip 	allows remote tripping of the device.			
	24Vac - 415Vac 12V - 130Vdc	1	1	MZ 203
	24 - 48Vac 12 - 48Vdc	1	1	MZ 204
Under voltage release 	allows MCB to be closed only when voltage is above 70% of Un. MCB will automatically trip when voltage falls by 35% of Un			
	48Vdc	1	1	MZ 205
	230Vac	1	1	MZ 206
Locking kit for the dolly of the device supplied without padlock.	allows locking of the device dolly in the on/off position. will accept two padlocks with hasps of 4.75mm diameter max.		1	MZN 175
Sealing Kit				MZN 176
Label kit	set of 12 labels for circuit indication. for multi-pole MCB's only.		10 sets	MZ 176



MZ 201



MZ 203



MZ 204




MZ 205



MZN 175

RCCB add-on blocks for MCB devices - Type AC - MB, MC, NC, ND, NR



Description
RCD add-on blocks for use with MCB ranges MB, MC, NC, ND, NR.
(manufactured since 01.01.00)

Technical data :
High sensitivity :
10-30 mA instant tripping
Medium sensitivity :
100-300 mA instant tripping
300 - 1A selective (time delay)

These devices are designed to be fitted on the right hand side of the 2, 3 and 4 poles MCB's.

The combination device than provides protection against overload, short circuits and earth leakage faults.

All devices have a test facility

All devices are type AC, protected against nuisance tripping and transient voltages




Nominal voltage : - 20, + 10%
2 poles 230V
3 and 4 poles : 230/400V
Test button : 230/400V

Comply with IEC1009

Connection capacities :


25 A : 6□ flexible cable
10□ rigid cable
40, 63 A : 16□ flexible cable
25□ rigid cable

□ For technical details see page 46

Designation	Sensitivity Δn	In/A	Width in I 17.5mm	Pack qty.	Cat. ref.	
 BD 226	10 mA	25A	2	1	BC 226	
		30 mA	25A	2	1	BD 226
	 time delayed  100 mA time delayed  300 mA time delayed  1A	40A	2	1	BD 241	
		63A	2	1	BD 264	
		100 mA	63A	2	1	BE 264
		300 mA	25A	2	1	BF 226
		40A	2	1	BF 241	
		63A	2	1	BF 264	
	63A	2	1	BN 264		
	63A	2	1	BP 264		
63A	2	1	BS 264			
 BD 364	30 mA	25A	2	1	BD 326	
		40A	3	1	BD 341	
		63A	3	1	BD 364	
	 time delayed  300 mA time delayed  1A	300 mA	25A	2	1	BF 326
		40A	3	1	BF 341	
		63A	3	1	BF 364	
 BD 426	30 mA	25A	2	1	BD 426	
		40A	3	1	BD 441	
		63A	3	1	BD 464	
	 time delayed  100 mA time delayed  300 mA time delayed  1A	100 mA	63A	3	1	BE 464
		300 mA	25A	2	1	BF 426
		40A	3	1	BF 441	
		63A	3	1	BF 464	
		63	3	1	BN 464	
		63A	3	1	BP 464	
		63A	3	1	BS 464	

RCCB add-on blocks for MCB devices - Type A

MB, MC, NC, ND, NR



Description
RCD add-on blocks for use with MCB ranges MB, MC, NC, ND, NR.
(manufactured since 01.01.00)

Technical data :
High sensitivity :
30 mA instant tripping
Medium sensitivity :
300 mA instant tripping

These devices are designed to be fitted on the right hand side of the 2, 3 and 4 poles MCB's
The combination device than provides protection against overload, short circuits and earth leakage faults.

All devices have a test facility
All devices are type A
Highly immunized against nuisance tripping for circuits which need continuity in supply (hospitals, computers, electronic ballasts...)
All devices integrate as well detection of nuisance tripping and transient voltages for AC and pulsating DC fault currents.

Nominal voltage : - 20, +10%
2 poles 230V
3 and 4 poles : 230/400V
Test button : 230/400V

Comply with IEC1009

Connection capacities :
25 A : 6□ flexible cable
10□ rigid cable
40, 63 A : 16□ flexible cable
25□ rigid cable


□ For technical details see page 46

Designation	Sensitivity Δn	In/A	Width in I 17.5mm	Pack qty.	Cat. ref.
-------------	------------------------	------	-------------------	-----------	-----------



BD 225

2 poles RCCB add-on blocks




30 mA	25A	2	1	BD 225
	40A	2	1	BD 240
	63A	2	1	BD 263
300 mA	25A	2	1	BF 225
	40A	2	1	BF 240
	63A	2	1	BF 263



BD 325

3 poles RCCB add-on blocks




30 mA	25A	2	1	BD 325
	40A	3	1	BD 340
	63A	3	1	BD 363
300 mA	25A	2	1	BF 325
	40A	3	1	BF 340
	63A	3	1	BF 363



BD 463

4 poles RCCB add-on blocks




30 mA	25A	2	1	BD 425
	63A	3	1	BD 463
300 mA	25A	2	1	BF 425
	40A	3	1	BF 440
	63A	3	1	BF 463

RCBO = association of 2 poles MCB \leq 63 A + 2 poles add-on block



MCB - NM, ND Type C, 80 to 125A - Type D, 80 & 100A



Description
Protection and control of circuits against overloads and short circuits.
- in commercial and industrial electrical distribution systems.

Technical data
Type C and D tripping characteristics
Tropicalisation T2
Breaking capacity : 10 000A to IEC 947-2
Voltage rating - 230V-400V
Current rating :

type C : 80, 100A & 125A
type D : 80, 100A

Positive contact indication :
red - contacts closed
green - contacts open

Connection capacity
50□ rigid cables
35□ flexible cables

Voltage marking as per IEC38 can be used on 240/415V 50Hz without derating

□ For technical details see pages 40-43

Designation	In/A	Width in 17.5mm	Pack qty.	Curve C Cat. ref.	Curve D Cat. ref.
-------------	------	-----------------	-----------	-------------------	-------------------



NM 280

Single pole MCB



80	1.5	1	NM 180	ND 180
100	1.5	1	NM 184	ND 184
125A	1.5	1	NM 190*	

Double pole MCB




80	3	1	NM 280	ND 280
100	3	1	NM 284	ND 284
125	3	1	NM 290*	




NM 380

Triple pole MCB



80	4.5	1	NM 380	ND 380
100	4.5	1	NM 384	ND 384
125	4.5	1	NM 390*	

Four pole MCB



80	6	1	NM 480	ND 480
100	6	1	NM 484	ND 484
125	6	1	NM 490*	



NM 480

* will not accept accessories (125A)

RCCB add-on blocks - Type AC / A

for use with 80/100A MCBs (NM)

RCCB add-on blocks

These devices are designed to be fitted to the right hand side of 2, 3, or 4 pole 80 and 100A circuit breakers.

The combination device then provides protection against overloads, short circuits and earth leakage faults.

Connection capacity

- 35□ flexible cables
- 50□ rigid cables

All devices have a test facility.

Nuisance tripping


As with all Hager devices the add on blocks are protected against nuisance tripping caused by transient voltages

□ For technical details see page 46




BD 285

Designation	Sensitivity $I\Delta n$	Width in 17.5mm	Pack qty.	Cat.ref. stand. type AC	Cat.ref. stand. type A
2 pole RCCB add-on blocks	30mA	2.5	1	BD 285	BD 284
suitable only for NM 280-NM 284	300mA	2.5	1	BF 285	BF 284
time delayed  300mA		2.5	1	BP 285	




BD 385

3 pole RCCB add-on blocks	30mA	2.5	1	BD 385	BD 384
suitable only for NM 380-NM 384	300mA	2.5	1	BF 385	BF 384
time delayed  300mA		2.5	1	BP 385	time




4 pole RCCB add-on blocks	30mA	4.5	1	BD 485	BD 484
suitable only for NM 480-NM 484	300mA	4.5	1	BF 485	BF 484
time delayed  300mA		4.5	1	BP 485	



example below: 2 pole MCB + 2 pole RCD add-on block.





Description
Protection and control of circuits against overloads and short-circuits in domestic electrical distribution systems. Fuse carriers for domestic cylindrical cartridge fuses, type B.

Comply with IEC 269

Connection capacity :

- 10□ flexible cables
- 16□ rigid cables

Technical data
Delivered without cartridge fuse. The LBX and LX series are delivered with a lighting push button to check the status of the cartridge fuse.

Designation	Characteristics	Width in 17.5mm	Pack qty.	LB cat.ref.	LBX cat.ref.
-------------	-----------------	-----------------	-----------	-------------	--------------



L 125 L 325

Fuse carrier LB, 1 Ph + N

10 A - 250 V ~

1

12

L 124

L 324



16 A - 250 V ~

1

12

L 125

L 325

Fuse carrier LBX, 1 Ph + N with lighting push button

20 A - 400 V ~

1

12

L 126

L 326



25 A - 400 V ~

1

12

L 127

L 327


32 A - 400 V ~

1

12

L 128

L 328



LF 142

Cartridge fuses

10A - 8,5 x 23mm

10

LF 138

domestic, type gF

16A - 10,3 x 25,8mm

10

LF 139

breaking capacity :

- 4000 A : from 10 to 20 A

20A - 8,5 x 31,5mm

10

LF 140

- 8000 A : from 25 to 32 A

25A - 10,3 x 31,5mm

10

LF 141

32A - 10,3 x 38mm

10

LF 142



L 147

Box for spare cartridge fuses fixing on the DIN rail next to the fuse carrier without removing enclosure cover

delivered empty

1

10

L 147

insulating material, unbreakable, with drawer for cartridge fuses



L 105 L 305

Fuse carrier L 1 PH

10 A - 250 V ~

1

12

"L"

"LX"



16 A - 250 V ~

1

12

L 104

L 304

Fuse carrier LX 1 PH with lighting push button

20 A - 400 V ~

1

12

L 105

L 305



25 A - 400 V ~

1

12

L 106

L 306

Fuse carrier neutral

32 A - 400 V ~

1

12

L 107

L 307

with unremovable neutral cartridge

1


12

L 108

L 308

L 109

HRC fuse carrier range - L31, L38




Description
Protection and control of circuits against overloads and short-circuits in commercial and light industrial electrical distribution systems.

Max 32A- 400V-
- Comply with IEC269-2

Connection capacity :
16□ rigid cables
10□ flexible cables

Fuse carrier L31
for cylindrical cartridge fuses
8.5 x 31.5mm
Max 16A- 400V-
Fuse carrier L38
for cylindrical cartridge fuses
10.3 x 38mm
Max 20A- 500V-

□ For technical details see page 47

Designation	Description	Width in 17.5mm	Pack qty.	L31 cat.ref.	L38. cat.ref.
	Single pole fuse carrier	1 phase	1	12	L 401 L 501
		1 phase + indic.light	1	12	L 431 L 531
	Double pole fuse carrier	1 phase + neutral	1	12	L 402 L 502
		1 phase + neutral + indic. light	1	12	L 432 L 532
		1 phase + neutral	1	12	L 406 L 506
		2 phases	1	12	L 412 L 512
	Triple pole fuse carrier	3 phases	3	4	L 403 L 503
		Four pole fuse carrier	3 phases + neutral	4	3
Indication labelling for fuse carrier L31, L38, L51		labels : ratings	10 stripes	L 055	
stripes of 50 stickers :			1 L 055 = 1 stripe		
- with ratings 0.16 to 32A					
- with letters and figures :					
2 stripes N, PE, L1, L3				3 kits	L 053
1 stripe 1 to 100				1 L 053 = 1 kit	
1 stripe 101 to 200					



L 401 L 431




L 406 L 402



L 404





L 055



L 053



L 022



for : 2	20	L 022
3	20	L 023
4	20	L 024
5	20	L 025

HRC fuse carrier range - L51

Description
Protection and control of circuits against overloads and short-circuits in commercial and industrial distribution systems.

Technical data
For cylindrical fuses
14 x 51mm
50A- 690V AC
50-60 Hz

Comply with IEC947-3

Fuse carriers type LS 6xx can be equipped with following accessories :
- indicating light : for indication of the fuse status.
- auxiliary switch : for indication of fuse blown condition

LR type will not accept accessories

Connection capacity :
35□ rigid cables
25□ flexible cables

□ For technical details see page 47



LS 601



LS 604



LS 672

Designation	Description	Width in I 17.5mm	Pack qty.	LR 6xx cat.ref.	LS 6xx cat.ref.
Single pole carrier	1 phase	1 1/2	1	LR 601	LS 601
Two pole carrier	2 phases	3	1	LR 602	LS 602
	1 phase + neutral link	3	1	LR 612	LS 612
Three pole carrier	3 phases	4.5	1	LR 603	LS 603
Four pole carrier	3 phases +neutral link	6	1	LR 604	LS 604
Auxiliary switch	for fuses 14 x 51 with striker pins	5A - 250V~ 1 c/o contact single pole	1		LS 670
	for fuses 14 x 51 with striker pins	three pole	1		LS 671
Indicating light	230V~ indication of blown or missing fuse link		1		LS 672

HRC fuse carrier range - L58

Description
Protection and control of circuits against overloads and short-circuits in commercial and industrial distribution systems.

Technical data
For cylindrical fuses
22 x 58mm
125A- 690V AC
50-60 Hz

Comply with IEC947-3

Fuse carriers type LS 7xx can be equipped with following accessories :

- indicating light : for indication of the fuse status.
- auxiliary switch : for indication of fuse blown condition

LR type will not accept accessories

Connection capacity :

- 50□ rigid cables
- 35□ flexible cables

□ For technical details see page 47

Designation	Description	Width in 17.5mm	Pack qty.	LR 7xx cat.ref.	LS 7xx cat.ref.
-------------	-------------	-----------------	-----------	-----------------	-----------------

Single pole carrier	1 phase	2	1	LR 701	LS 701
---------------------	---------	---	---	--------	--------



LS 701

Two pole carrier	2 phases	4	1	LR 702	LS 702
------------------	----------	---	---	--------	--------

	1 phase + neutral link	4	1	LR 712	LS 712
--	------------------------	---	---	--------	--------

Three pole carrier	3 phases	6	1	LR 703	LS 703
--------------------	----------	---	---	--------	--------



LS 703

Four pole carrier	3 phases + neutral link	8	1	LR 704	LS 704
-------------------	-------------------------	---	---	--------	--------



LS 770

Auxiliary switch for fuses 22 x 58 with striker pins	5A - 250V ~ 1 c/o contact single pole		1		LS 770
--	---	--	---	--	--------

	three pole		1		LS 771
--	------------	--	---	--	--------

Indicating light	230V ~ indication of blown or missing fuse link		1		LS 672
-------------------------	--	--	---	--	--------




LS 672

Adaptor for assymetric rails for series L51 and L58			20		L 065
--	--	--	----	--	-------



L 065

2 pole and 4 pole RCCBs



Description

To open a circuit automatically in the event of an earth fault between phase and earth, and/or neutral and earth. A wide range of current ratings and sensitivities are available. Suitable for domestic, commercial, industrial applications.

Technical data

Specification IEC1008
Tropicalisation T2

Sensitivities (fixed) :

10, 30, 100, 300mA and 500mA

Terminal capacities :

16-63A rigid 25□
flexible 16□
80&100A rigid 50□
flexible 35□

Features

Positive contact indication is provided by the rectangular flag indicator
Red = closed
Green = open.
Indication of trip is provided by the oval flag indicator
Yellow = tripped.
All RCCB's have trip free mechanisms and can be padlocked either 'on' or 'off'.

Operating voltage

2P - 127-230V AC 50Hz (+6%,-10%)
4P - 230 - 400V AC 50Hz (+6%,-10%)

Voltage marking as per IEC38 can be used on 240/415V 50Hz without derating

Width in 17.5mm modules |
2P - 2 |
4P - 4 |

□ For technical details see pages 48-51



CD 241J



CD 441J

Sensitivity	Current rating	Pack qty	Ref 2 pole avai. from 1.09.05	Ref 2 pole current range	Ref 4 pole avai. from 1.09.05	Ref 4 pole current range
10mA	16A	1	CC 217J	CC 217Z		
	30mA					
	25A	1	CD 226J	CD 226Z	CD 426J	CD 426Z
	40A	1	CD 241J	CD 241Z	CD 441J	CD 441Z
	63A	1	CD 264J	CD 264Z	CD 464J	CD 464Z
30mA - Type A AC and pulsating DC residual current	80A	1		CD 281Z		CD 480Z
	100A	1		CD 285Z		CD 485Z
	25A	1	CD 225J	CD 227T	CD 425J	CD 427T
	40A	1	CD 240J	CD 242T	CD 440J	CD 442T
	63A	1	CD 263J	CD 265T	CD 463J	CD 465T
100mA	25A	1	CE 226J	CE 226Z	CE 426J	CE 426Z
	40A	1	CE 241J	CE 241Z	CE 441J	CE 441Z
	63A	1	CE 264J	CE 264Z	CE 464J	CE 464Z
	80A	1		CE 281Z		CE 481Z
	100A	1		CE 285Z		CE 485Z
300mA	25A	1	CF 226J	CF 225U	CF 426J	CF 426Z
	40A	1	CF 241J	CF 241Z	CF 441J	CF 441Z
	40A	1			CP 441J	CP 445F
	63A	1	CF 264J	CF 264Z	CF 464J	CF 464Z
	63A	1		CP 265F		
	63A	1			CP 464J	CP 465F
	80A	1		CF 281Z		CF 481Z
100A	1		CF 285Z		CF 485Z	
300mA - Type A AC and pulsating DC residual current	25A	1	CF 225J		CF 425J	
	40A	1	CF 240J		CF 440J	
	63A	1	CF 263J		CF 463J	
500mA	80A	1				CG 481Z
	100A	1				CG 485Z


Accessories for 2 pole and 4 pole RCCBs



MZN 175

<i>Sensitivity</i>	<i>Current rating</i>	<i>Pack qty</i>	<i>Ref 2 pole avai. from 1.09.05</i>	<i>Ref 2 pole</i>	<i>Ref 4 pole avai. from 1.09.05</i>	<i>Ref 4 pole</i>
Accessories terminal covers	16A-63A	10 sets	CZN 005	CZ 005	CZN 006	CZ 006
	80A-100A	10 sets		CZ 007		CZ 008
Auxiliary + alarm switch	1 I wide for ON/OFF & trip indication					CZ 001
locking kit for the dolly of the device supplied without padlock.	this allows locking of the device dolly in the on/off position. will accept two padlocks with hasps of 4.75mm diameter max.					MZN 175

RCBO (residual circuit breaker with overload) Type B and C SP&N with neutral lead



Description
Compact protection devices which provide MCB overcurrent protection and RCD earth leakage protection in a single unit.

Complies to IEC1009

Technical data
The units are available with current ratings of 6A, 10A, 16A, 25A, 32A and 40A. The device switches both the phase and neutral conductors. All ratings

have 30mA and 300mA earth leakage protection. The units feature indicators which show whether tripping is due to an overcurrent or earth leakage fault.

Voltage rating - 110-230V
50/60Hz
Current rating – 6-40A.
Mechanical life :
20 000 operations.
Breaking capacity : 4 500A and 6 000A

Connection capacity
25□ rigid cables
16□ flexible cables


Designation	Breaking capacity	In/A	Width in I 17.5mm	Pack qty.	Ref. type B available as from 01.09.05	Ref. type C available as from 01.09.05
-------------	-------------------	------	-------------------	-----------	--	--

RCBO Type AC - 30mA	4,5kA	6A	2	1	AD806J	AD856J
		10A	2	1	AD810J	AD860J
		16A	2	1	AD816J	AD866J
		20A	2	1	AD820J	AD870J
		25A	2	1	AD825J	AD875J
		32A	2	1	AD832J	AD882J
	6kA	40A	2	1	AD840J	AD890J
		6A	2	1	AD906B	AD956B
		10A	2	1	AD910B	AD960B
		16A	2	1	AD916B	AD966B
		20A	2	1	AD920B	AD970B
		25A	2	1	AD925B	AD975B
		32A	2	1	AD932B	AD982B
		40A	2	1	AD940B	AD990B
RCBO Type AC - 300mA	6kA	6A	2	1		AF956B
		10A	2	1		AF960B
		16A	2	1		AF966B
		20A	2	1		AF970B
		25A	2	1		AF975B
		32A	2	1		AF982B
		40A	2	1		AF990B
RCBO Type A - 30mA	6kA	6A	2	1	AD906J	AD956J
		10A	2	1	AD910J	AD960J
		16A	2	1	AD916J	AD966J
		20A	2	1	AD920J	AD970J
		25A	2	1	AD925J	AD975J
		32A	2	1	AD932J	AD982J
		40A	2	1	AD940J	AD990J
RCBO Type A - 300mA	6kA	6A	2	1		AF956J
		10A	2	1		AF960J
		16A	2	1		AF966J
		20A	2	1		AF970J
		25A	2	1		AF975J
		32A	2	1		AF982J
		40A	2	1		AF990J



AD 916J

RCBO - single pole



Description

Compact protection devices which combine the overcurrent functions of an MCB with the earth fault functions of an RCD in a single unit. A range of sensitivity and current ratings are available for use in domestic commercial and industrial applications

Technical data

Specification complies to IEC1009

Sensitivities :

Fixed : 30mA, 100mA and 300mA
Selectivity : 100mA, 300mA

Terminal capacities

16□ rigid, 10□ flexible

Features

1 module devices provide a compact solution for installation in consumer units & distribution boards, for individual installations. These devices are 1P & solid neutral.

Operating voltage

110-230V AC 50/60Hz

Flying neutral lead length

700mm



AD 110Z

<i>Designation</i>	<i>In/A</i>	<i>Width in I 17.5mm</i>	<i>Pack qty.</i>	<i>C curve cat. ref.</i>
RCBO, 6000A to IEC 898, C curve, 30mA sensitivity	6	1	1	AD 106Z
	10	1	1	AD 110Z
	16	1	1	AD 116Z
	20	1	1	AD 120Z
	25	1	1	AD 125Z
	32	1	1	AD 132Z
	40	1	1	AD 140Z
	45	1	1	AD 127
50	1	1	AD 128	
RCBO, 6000A to IEC 898, C curve, 100mA sensitivity	6	1	1	AE 106Z
	10	1	1	AE 110Z
	16	1	1	AE 116Z
	20	1	1	AE 120Z
	25	1	1	AE 125Z
	32	1	1	AE 132Z
40	1	1	AE 140Z	
RCBO, 6000A to IEC 898, C curve, 300mA sensitivity	20	1	1	AF 120Z
	25	1	1	AF 125Z
	32	1	1	AF 132Z
	40	1	1	AF 140Z
RCBO, 10000A to IEC 898, C curve, 30mA sensitivity	6	1	1	AD 184
	10	1	1	AD 185
	16	1	1	AD 187
	20	1	1	AD 188
	25	1	1	AD 189
	32	1	1	AD 190
40	1	1	AD 191	
RCBO, 6000A to IEC 898, C curve, 100mA sensitivity selective version	50	1	1	AN 150Z
RCBO, 6000A to IEC 898, C curve, 300mA sensitivity selective version	50	1	1	AP 150Z



MZN 175

Locking kit

this allows the locking of the device dolly in ON/OFF positions. It is possible to padlock the device with 2 padlocks.

MZN 175

Earth leakage relays

Earth leakage relays with separate detection torroids.

These devices ensure protection of electrical installations and the protection of persons against direct and indirect contacts.

Transform circuit breakers and free-tripping switches with voltmeter triggers into earth leakage devices.

Barograph version:

Signalisation of default current by a barograph, display in % the level of current before setting of relay (5 to 75%). An output contact prealarm to remote every overflow of 50% of $I_{\Delta n}$.

Common characteristics

- positive security : relay tripping when break in relay/core link, and blinking of default LED
- Default storage with control of tripping sequence (reset),
- test-button for default simulation with control of tripping sequence.
- Nuisance tripping protection and immunity type A and HI
- Tripping on DC default current
- Display of default current by LED,
- LED for power supply

Supply voltage : 230 V
frequency : 50/60 Hz

Connection capacity :
- rigid 1,5 to 10[□]
- flexible 1 to 6[□]
max. length of wires :
remote test and reset : 20 m

According to electromagnetic compatibility (CEM)
According to standards :
CEI 60947-2 annex B
CEI 60755 CEI 61008 - 1
CEI 61543

For technical details see pages 52



HR 400

Designation	Characteristics	Width in ■ 17,5 mm	Ref.
Earth leakage relays standard version 1 C/O	instant strip, adjustable sensitivity, $I_{\Delta n}$: 30 mA	2	HR 400
	300 mA	2	HR 402



HR 410

Earth leakage relays standard version 1 C/O adjustable sensitivity $I_{\Delta n}$: 0,03 - 0,1 - 0,3 - 0,5 - 1 - 3 5 - 10A	standard version 1 OF	3	HR 410
	- display of earth leakage current - positive safety output - 50% default output with optical scale display	3	HR 420



HR 420

adjustable time delay : 0 - 0,1 - 0,3 - 0,4 - 0,5 - 1s - 3s		5	HR 425
	- display of earth leakage current - positive safety output - 50% default output with optical scale display - external test and reset		

Torroids

Detection torroid

Torroids can be associated with all differential relays of HR range. They meet all requirements of electrical distribution.

- 6 circular section torroids of Ø 30 to Ø 210 mm
- 3 closed rectangular torroids
- 5 rectangular section torroids opening for renovation (can be installed without disconnecting cables).

Mounting :

- either directly on cable or metal strip
- or on perforated kits in Univers and Quadro.
- HR 800 can be clipped on DIN rail

Installation instruction :

- fix torroid on rectilinear part of cables
- put cables or bars inside the torroid
- PE conductor must not run through the torroid

Connection of cables

- rigid 1,5 to 4[□]
- flexible 1 to 6[□]
- max. length core/relay
- 50 m max with twisted cable of 1,5 mm²

For technical details see pages 53-54

Designation	Characteristics	Ref.
	Circular section torroids	
	Ø 30 mm	HR 800
	Ø 35 mm	HR 801
	Ø 70 mm	HR 802
	Ø 105 mm	HR 803
	Ø 140 mm	HR 804
	Rectangular section torroids	
	- closed	
	70 x 175 mm	HR 830
	115 x 305 mm	HR 831
	150 x 350 mm	HR 832
	- opening	
20 x 30 mm	HR 820	
50 x 80 mm	HR 821	
80 x 80 mm	HR 822	
80 x 120 mm	HR 823	
80 x 160 mm	HR 824	


HR 802

HR 830

HR 820

HR 822

Isolating switches



Description
for use as a switch
disconnecter in all types of
circuit.

Complies with :
- IEC 60947-3 (In 16 to 100A)
- EN 669.1 (In 16 to 63A)

Technical data
In : 16, 25, 32A
AC 21A duty specification
connection capacity:
10□ rigid cables
6□ flexible cables
In : 40, 63, 80A (1 pole)
AC 22B duty specification
connection capacity:
25□ rigid cables
16□ flexible cables

In : 80A (2 to 4 poles), 100A
AC 22B duty specification
connection capacity:
50□ rigid cables
35□ flexible cables

Designation	Characteristics	Width in 17.5mm	Pack qty.	Cat. ref.
-------------	-----------------	-----------------	-----------	-----------



SB 140

Single pole						
 	1 x 16A	250V~	1	12	SB 116	
	1 x 16A	250V~	1	1	SB 116V	
	with pilot light					
	1 x 25A	250V~	1	12	SB 125	
	1 x 25A	250V~	1	1	SB 125V	
	with pilot light					
	1 x 32A	250V~	1	1	SB 132	
	1 x 32A	250V~	1	1	SB 132V	
	with pilot light					
	1 x 40A	250V~	1	1	SB 140	
	1 x 63A	250V~	1	1	SB 163	
	1 x 80A	250V~	1	12	SB 180	
	1 x 100A	250V~	1	1	SB 199	



SB 232

Double pole						
 	2 x 16A	250V~	1	1	SB 216	
	2 x 16A	250V~	1	1	SB 216V	
	with pilot light					
	2 x 25A	250V~	1	12	SB 225	
	2 x 25A	250V~	1	1	SB 225V	
	with pilot light					
	2 x 32A	250V~	1	1	SB 232	
	2 x 32A	250V~	1	1	SB 232V	
	with pilot light					
	2 x 40A	250V~	1	1	SB 240	
	2 x 63A	250V~	1	6	SB 263	
	2 x 80A	250V~	1	1	SB 280	
2 x 100A	250V~	1	1	SB 299		



SB 240

Triple pole						
 	3 x 16A	400V~	2	1	SB 316	
	3 x 25A	400V~	2	1	SB 325	
	3 x 32A	400V~	2	1	SB 332	
	3 x 32A	400V~	3	1	SB 332Q	
	large terminals					
	3 x 40A	400V~	3	1	SB 340	
	3 x 63A	400V~	3	1	SB 363	
	3 x 80A	400V~	3	1	SB 380	
	3 x 100A	400V~	3	1	SB 399	



SB 399

Designation	Characteristics	Width in 17.5mm	Pack qty.	Cat. ref. neutral right	Cat. ref. neutral left
-------------	-----------------	-----------------	-----------	-------------------------	------------------------

 	Four pole					
	4 x 16A	400V~	2	1	SB 416	SB 416F
	4 x 25A	400V~	2	1	SB 425	SB 425F
	4 x 32A	400V~	2	1	SB 432	SB 432F
	4 x 40A	400V~	4	1	SB 440	SB 440F
	4 x 63A	400V~	4	1	SB 463	SB 463F
	4 x 80A	400V~	4	1	SB 480	SB 480F
	4 x 100A	400V~	4	1	SB 499	SB 499F

2 way / centre - off changeover modular switches



SF 118F

Designation	Characteristics	Width in 17.5mm	Pack qty.	Cat. ref.
-------------	-----------------	-----------------	-----------	-----------

Switch, 2 ways single pole	1 x 25A 250V~	1	12	SF 118F
-----------------------------------	---------------	---	----	----------------



Double pole	2 x 25A 250V~	1	12	SF 115
--------------------	---------------	---	----	---------------



Double pole	2 x 25A 250V~	2	6	SF 218F
--------------------	---------------	---	---	----------------




SF 219F

Switches centre - off changeover single pole	1 x 25A 250V~	1	12	SF 119F
	1 x 40A 250V~	1	12	SF 119G



double pole	2 x 25A 250V~	2	6	SF 219F
--------------------	---------------	---	---	----------------



	2 x 40A 250V~	2	6	SF 219G
--	---------------	---	---	----------------

	3 x 40A 250V~	3	4	SF 319G
--	---------------	---	---	----------------

	4 x 40A 250V~	4	3	SF 419G
--	---------------	---	---	----------------



SZ 011

Handle link pin for switch handles	1 set includes 5 pins 2 mod width 5 pins 3 mod width 5 pins 4 mod width		1 set	SZ 011
---	--	--	-------	---------------

Surge protective devices type 1

This type of surge protective devices are recommended on electric installations where the buildings are fitted with lightning conductor. The minimum value of shock current is $I_{imp} = 12,5 \text{ kA}$.

With a discharge current wave $10/350 \mu\text{s}$ (I_{imp}) which is similar to lightning current on direct impact, those SPD's must have the capacity to flow out this energizing wave.

Monobloc SPD's type 1 have a LED for well functioning for each phase on the front.

- connection capacity:
 - 35^{sq} flexible conductor,
 - 50^{sq} rigid conductor
- complies with EN 61-643.11
- For technical details see pages 55-59



SPA 412A

Designation	Characteristics	Width in ■ 17,5 mm	Ref.
SPD's type 1 I_{imp} 12,5 kA	2 pole 1 Ph + N Up : 2,5 kV at In	4	SPA 212A
Un : 230/400 V ~ 50/60 Hz	4 poles 3 Ph + N Up : 2,5 kV at In	8	SPA 412A

Surge protective devices for general protection

SPDs with plug in cartridge with very high, high and medium discharge current capacity (65 kA, 40 kA and 15 kA).

SPDs with plug in cartridge ensure :
 - general protection of electric equipment,
 - protection in common and differential mode for domestic, industrial and commercial buildings.

Common characteristics :
 SPDs with base and cartridges.

Available in 2 versions :
 SPDs with base and plug in cartridges with an end of life indication LED
 SPDs with base and auxiliary contact for remote signalling and plug in cartridges with reserve protection indicator .

This version, with reserve indicator, shows the intermediary state, with indication of the need to change the cartridge before disconnection, but keeps the maximal protection capacity till the end.

For remote signalling, an auxiliary contact (R version) is used to report the information of condition indication until the end of life of the product.

The cartridge allows simple replacement without the need to cut-off the power supply
 SPDs are equipped with integrated thermic and dynamic disconnection

- connection capacity of terminal blocks, (L, N/E) :
 - 16^{sq} flexible conductor,
 - 25^{sq} rigid conductor
 for auxiliary contact :
 - 0,5^{sq} mini
 - 1,5^{sq} maxi
- degree of protection : IP 203 (in enclosure).

For technical details see pages 55-59




SPN 265R





SPN 465R

Designation	Characteristics	Width in ■ 17,5 mm	Ref.
SPDs with plug in cartridge I_{max} 65 kA	2 poles 1 Ph + N with reserve indicator and remote signalling Up : 1,3 kV at In	2	SPN 265R
Un : 230/400 V ~ 50/60 Hz	4 poles 3 Ph + N with reserve indicator and remote signalling Up : 1,5 kV at In	4	SPN 465R



Surge protective devices for general protection

	Designation	Characteristics	Width in ■ 17,5 mm	Ref.
 SPN 240R	SPDs with plug in cartridge	- single pole 1 Ph Up : 2 kV at In	1	SPN 140C
	I max. 40 kA Un : 230/400 V ~ 50/60 Hz	- 2 poles 1 Ph + N with reserve indicator and remote signalling Up : 1,2 kV at In	2	SPN 240R
		- 2 poles 1 Ph + N Up : 1,2 kV at In	2	SPN 240D
		- 4 poles 3 Ph + N with reserve indicator and remote signalling Up : 1,2 kV at In	4	SPN 440R
		- 4 poles 3 Ph + N Up : 1,2 kV at In	4	SPN 440D
 SPN 415R	SPDs with plug in cartridge	- 2 poles 1 Ph + N with reserve indicator and remote signalling Up : 1,0 kV at In	2	SPN 215R
	I max. 15 kA Un : 230/400 V ~ 50/60 Hz	- 2 poles 1 Ph + N Up : 1,0 kV at In	2	SPN 215D
		- 4 poles 3 Ph + N with reserve indicator and remote signalling Up : 1,0 kV at In	4	SPN 415R
		- 4 poles 3 Ph + N Up : 1,0 kV at In	4	SPN 415D

Replacement cartridges for SPDs with plug in cartridge

Replacement cartridges

The cartridge allows simple replacement without the need to cut-off the power supply.

Cartridges are available for all discharge currents (65 kA, 40 reserve protection indication).

A keying system exists to prevent a line cartridge being interchanged by mistake with a neutral and visa versa

For technical details see pages 55-59

	Designation	Characteristics	Width in ■ 17,5 mm	Ref.
 SPN 065R	Replacement cartridges	Phase for : SPN 265R, SPN 465R		SPN 065R
		SPN 140C		SPN 040C
		SPN 240R, SPN 440R		SPN 040R
		SPN 240D, SPN 440D		SPN 040D
		SPN 215R, SPN 415R		SPN 015R
		SPN 215D, SPN 415D		SPN 015D
 SPN 065N	Remark : for a replacement of cartridges, choose only the same reference as the previous cartridge.	Neutral for: SPN 265R, SPN 465R,		SPN 065N
		SPN 240R, SPN 440R, SPN 215R, SPN 415R SPN 240D, SPN 440D, SPN 215D, SPN 415D		SPN 040N

Surge protective devices for fine protection

SPDs with low valoltage protection level

To protect very sensitive electronic equipment. The fine protection completes the main protection and can protect 1 or several electronic devices. Optimal coordination is obtained when cascaded with a main protection device (lower Up see table below)

Protection is assured in both common and differential modes.

Discharge current :
I max. 8 kA (8/20 wave).

A green LED on the front face indicates the status of the SPD connected in series with the equipment that needs to be protected. Connected in series with the equipment that needs to be protected.

Suitable for every earthing system.

Connection capacity :
- 6^{mm} flexible conductor
- 10^{mm} rigid conductor .

Degree of protection : IP 20 (in enclosure).

complies with NF EN 61-643-11 september 2002

For technical details see pages 55-59



SPN 408S

Designation	Characteristics	Width in 17,5 mm	Ref.
SPD with low voltage protection level	2 poles 1 Ph + N	2	SPN 208S
Un : 230/400 V ~ 50/60 Hz	4 poles 3 Ph + N	3	SPN 408S
Up (Ph/ N/ \perp) : 1,2 kV at In Up (Ph/N) : 1 kV at In	Voltage protection level with a main + fine protection : Up ≤ 800 V		

SPDs for telephone lines

SPDs for telephone lines.

For the protection of receiver against transient current surge vehicled by telephone lines (fax, modem, etc...) Protection is assured in both common and differential modes

In-line connection on telephone line with receiver to be protected.

Discharge current :
I max 10 kA (8/20 wave).

Connection capacity
- 0,5 à 2,5^{mm} flexible conductor
- 0,5 à 2,5^{mm} rigid conductor

Degree of protection : IP 10 (in enclosure).

Complies with IEC 61643-21

For technical details see pages 55-59



SPN 505

Designation	Characteristics	Width in 17,5 mm	Ref.
Voltage surge protection for analog telephone lines	Un : 130 V Up : 600 V	1	SPN 505
Voltage surge protection for digital telephone lines	Un : 40 V Up : 600 V	1	SPN 504

Motor starters

Description
to ensure localised control and protection of single and three phase motors.

Technical data
– adjustable thermal relay
– AC3 utilisation category

Connection capacity
2 conductors
max size 1 to 4□ flexible
1.5 to 6□ rigid

Options
under voltage release: MZ 528N,
MZ 529N
auxiliary contacts: MZ 520N,
MZ 527N
alarm contact: MZ 527N,

Complies with IEC 947-1,
IEC 947-2

Breaking capacity :
Ic (kA)
230 V ~ 400 V ~

0,16 à 10 A	100	100
16 à 25 A	16	16

□ For technical details,
see page 60



MM 501N

Designation	current setting	Stand.power motors 50/60Hz	Ratings of 3 phase (AC3 category)	Width in I 17.5mm	Pack qty.	Cat. ref.
Motors starters		230V (kW)	400V (kW)			
	0.1 - 0.16A	-	-	2 1/2	1	MM 501N
	0.16 - 0.24A	-	0.06	2 1/2	1	MM 502N
	0.24 - 0.4A	0.06	0.09	2 1/2	1	MM 503N
	0.4 - 0.63A	0.09	0.12	2 1/2	1	MM 504N
	0.63 - 1A	0.12	0.25	2 1/2	1	MM 505N
	1 - 1.6A	0.25	0.55	2 1/2	1	MM 506N
	1.6 - 2.5A	0.37	0.75	2 1/2	1	MM 507N
	2.5 - 4A	0.75	1.5	2 1/2	1	MM 508N
	4 - 6.3A	1.1	2.2	2 1/2	1	MM 509N
	6.3-10A	2.7	4	2 1/2	1	MM 510N
	10-16A	4	7.5	2 1/2	1	MM 511N
	16-20A	5.5	9	2 1/2	1	MM 512N
	20-25A	7.5	12.5	2 1/2	1	MM 513N

	Designation	Characteristics	Width in ■ 17,5 mm	Ref.
 <p>MZ 520N</p>	Auxiliary contacts connection of MZ520N on the right side of motor starter, MZ522N connected directly on front of motor starter and cannot be mounted behind modular plates.	1 C + 1 O 3,5 A - 230 V ~ 2 A - 400 V ~	1/2	MZ 520N
		1 C 1 A - 230 V ~ 400 V ~	1/2	MZ 522N
 <p>MZ 527N</p>	Default signal contact mounting on the right side of motor starter	1 C : short-circuit 3,5 A - 230 V ~ 2 A - 400 V ~	1/2	MZ 527N
		1 C : overload 1 short-circuit		
 <p>MZ 523N</p>	Shunt trip mounting on the left side of motor starter	230 V ~ - 50 Hz	1	MZ 523N
		Under voltage release mounting on the left side of motor starter	230 V ~ - 50 Hz	1
 <p>MZ 528N</p>	Under voltage release mounting on the left side of motor starter	400 V ~ - 50 Hz	1	MZ 529N
		Surface mounting enclosure for waterproof motor starter I. 80 x h. 158 x p. 125,5 mm	with external rotary handle activates motor starter without opening the enclosure ○ 4 x M25	
 <p>MZ 521N</p>	Emergency stop button emergency stop : IP 65 Remote emergency stop button with key synchronizing unlocking with key IP67	allow remote "emergency stop" of motor starter via tripping auxiliary		MZ 530N
		1 C + 1 O 230 / 400 V ~		MZ 531N
 <p>MZ 530N</p>	 <p>MZ 531N</p>			



=



+



This "made by hager" symbol is your guarantee to receive the very best that hager has to offer.

Over time, it will replace the hologram which will be progressively withdrawn.

Every MCB, RCCB and RCBO that bears this new symbol has been carefully crafted in one of our hager owned factories.




hager

the success is in the system

hager 5

Technical information

- 38 Circuit protection
- 40 Miniature circuit breakers
- 44 Auxiliaries for MCBs and RCDs
- 45 Transformer protection and lighting circuits
- 46 RCD add on blocks
- 47 HRC fuse carriers
- 48 RCCBs
- 52 Earth fault protection relays
- 53 Torroids for earth fault protection relays
- 55 Surge protective device
- 60 Motor starters



Basic Principles

The proper selection of the correct circuit protective device requires an understanding of the potential hazards against which protection for safety is required. The Wiring Regulations identify several hazards:

- electric shock
- thermal effects
- overcurrent
- undervoltage
- isolation

Electric shock - is divided into two parts:

- direct contact: contact with parts which result in an electric shock in normal service
- indirect contact: contact with exposed conductive parts which result in an electric shock in case of a fault.

To protect against direct contact the Wiring Regulations suggest the following basic measures should be taken:

- (1) by insulation of live parts
- (2) by enclosures or barriers
- (3) by obstacles
- (4) by placing out of reach

To protect against indirect contact the Wiring Regulations suggest the following basic measures should be taken:

- (1) earthed equipotential bonding and automatic disconnection of supply
- (2) use of class II equipment or equivalent insulation
- (3) non-conducting location
- (4) earth-free local equipotential bonding
- (5) electrical separation

Of these five measures, the first is by far the most commonly used - (1) earthed equipotential bonding and automatic disconnection of supply:

In each installation main equipotential bonding conductors shall connect the main earthing terminal of the installation; this metalwork comprises exposed conductive parts which are part of the electrical installation itself and extraneous conductive parts including the following:

- main water pipes
- gas installation pipes
- other service pipes and ducting
- risers of central heating and air conditioning systems
- exposed metal parts of the building structure

This bonding creates a zone within which any voltages appearing between exposed conductive parts and extraneous conductive parts, are minimised; the earth fault loop impedance must have a value low enough to allow sufficient current to flow for the circuit protective device to operate rapidly to disconnect the supply; disconnection must be sufficiently fast so that voltages appearing on the bonded metalwork cannot persist long enough to cause danger; depending on the operating characteristics of the protective device and the earth impedance, such disconnection may be achieved either by overcurrent devices, Fuses, Miniature Circuit Breakers, (i.e. MCBs) or by Residual Current Devices, (i.e. RCDs).

Thermal Effect - refers to heat generated by the electrical equipment in normal use and under fault conditions. The proper selection of equipment complying with the latest product standards is essential in providing protection against thermal effects.

Overcurrent - is defined as a current exceeding the rated value of the circuit components. It may be caused by the overloading of a healthy circuit or it may take the form of a short-circuit current, defined as an "overcurrent resulting from a fault of negligible impedance between live conductors having a difference in potential under normal operating conditions". Overcurrent protection may be provided by using fuses or circuit breakers singly or in combination.

Undervoltage - refers to the dangers that could be caused by the reduction or loss in voltage and the subsequent restoration, such as the unexpected re-starting of motors or the automatic closing of protective devices. The proper selection of control and protective devices must take the protection against undervoltage into consideration.

Isolation - every circuit shall be provided with means of isolation (except in certain cases) to prevent or remove hazards associated with the installation, equipment and machines. The new standards for circuit breakers and switch-fuses now take this into account.

Protection against shock by indirect contact


Indirect contact - is the contact of persons or livestock with exposed conductive parts made live by a fault and which may result in electric shock. An example would be where the insulation of an electric heater has broken down resulting in a live conductor internally touching the casing. This could result in the heater casing being raised to a hazardous voltage level, causing electric shock to a person touching it.

Two important measures must be taken to prevent this hazard:

- the impedance of circuit conductors is kept to a minimum. The earth fault loop impedance (Z_s) is used as a measure of the circuit impedance under fault conditions.
- the overcurrent device protecting the circuit is selected to rapidly disconnect an earth fault.

The effect of these two measures is inter-related.

1. By ensuring that the circuit protective conductor is of a low impedance, the voltage to which the live casing is raised, under fault conditions, is kept to a minimum.
2. The low impedance path provided by the circuit conductors and the circuit protective conductor will result in a high level of current in the event of an earth fault. This high fault current ensures that the overcurrent protective device will disconnect the fault in a short time, reducing the interval during which the casing of the faulty equipment is live.



Components of earth fault loop impedance (Z_s) in a system. (Earth fault at load between conductor and casing).

$$Z_s = Z_e + (R_1 + R_2)$$

Earth fault loop impedance (Z_s)

To ensure the impedance of conductors in a circuit is sufficiently low the system designer has to establish the value of the earth fault loop impedance.

Z_s - is a measure of the earth fault current loop, comprising the phase conductor and the earth conductor. It comprises the complete loop including the winding of the transformer from which the circuit is supplied as defined by the following:

Z_e - is the part of the earth fault loop impedance external to the installation, its value can be measured or a nominal value can be obtained from the supply authority.

$(R_1 + R_2)$ - where R_1 is the resistance of the phase conductor within the installation and R_2 is the resistance of the circuit protective conductor. These two components constitute the loop impedance within the installation.

Therefore: $Z_S = Z_e + (R_1 + R_2)$

Once the value of Z_S has been established a suitable overcurrent protective device has to be selected to ensure disconnection of an earth fault within the specified time. The times are:

- 5 seconds for fixed equipment.
- For portable equipment and for fixed equipment installed outside the equipotential bonding zone, the disconnection times are dependent on the nominal voltage to earth, i.e. 220 to 277 volts = 0.4 seconds.

Z_S by calculation

To establish whether the relevant disconnection time can be achieved a simple calculation must be made, based on Ohm's law:

$$I_f \text{ (fault current)} = \frac{U_0 \text{ (open circuit voltage)*}}{Z_S \text{ (earth fault loop)}}$$

* voltage between phase and earth (240V)

The fault current (I_f) must be high enough to cause the circuit protective device to trip in the specified time. This can be established by consulting the time/current characteristic for the protective device. If the maximum trip time for the fault current calculated is less than or equal to the relevant value (5s for fixed equipment; 0.4s for portable equipment) then compliance is achieved. It is important that when consulting the characteristic curve the worst case is used, i.e. the maximum tripping time including any tolerance. An example is shown in Figs 1 and 2.

Z_S by tables

The above procedure can be used for any type of protective device providing a time/current characteristic curve is available. Frequently, however, a much simpler method is available using tables listing maximum Z_S values which have been interpreted from the characteristic curves for the relevant devices. Providing the system Z_S is equal to or less than the value given in the table, compliance is achieved. Tables for a number of 'standard' devices (certain fuses and MCBs) are given in the Wiring Regulations.

Z_S too high

If the system Z_S value is too high to achieve rapid enough disconnection with the overcurrent protective devices available then it is necessary to use one of the two following methods:

- fit a cable with a larger cross-section and consequently a lower impedance. This may be a very expensive solution especially when the installation is complete before the problem is discovered.
- use a Hager residual current device (RCD). Subject to certain conditions being met this provides a simple and economical solution.

Example




Fig 2


Fig 2 shows a fixed circuit with an earth loop impedance Z_S of 0.7 ohms protected with an MT 132. The fault current (I_f) will therefore be $U_0/Z_S = 240/0.7 = 343A$
By referring to the characteristic for MT132 (see Fig 3) it can be seen

that the breaker will disconnect in 0.02 seconds for this current. The breaker therefore easily satisfies the requirement for disconnection in 5 seconds.

If the circuit Z_S was 2.0 ohms then the fault current would be: $240/2 = 120A$

and the disconnection time would be 10 seconds, in which case compliance would not be achieved.

Fig 3



Protection against overcurrent

Overcurrent - "A current exceeding the rated value. For conductors the rated value is the current-carrying capacity"

Overload Current - "An overcurrent occurring in a circuit which is electrically sound"

Short-Circuit Current - "An overcurrent resulting from a fault of negligible impedance between live conductors having a difference in potential under normal operating conditions."

Protection against Overload Current

For the protection against overload current, protective devices must be provided in the circuit to break any overload current flowing in the circuit conductors before it can cause a temperature rise which would be detrimental to insulation, joints, terminations or the surroundings of the conductors.

In order to achieve this protection the nominal current of the protective device I_n should be not less than the design current of the circuit I_b and that I_n should not exceed the current-carrying capacity of the conductors I_z , and that the current causing effective operation of the protective device I_2 does not exceed 1.45 times the current-carrying capacity of the conductor I_z , expressed as $I_b \leq I_n \leq I_z$
 $I_2 \leq 1.45I_z$

Protection against Short-Circuit Current

Protective devices must be provided to break any short-circuit current before it can cause danger due to thermal and mechanical (electro-dynamic) effects produced in the conductors and connections. The breaking capacity of the protective device shall not be less than the prospective short-circuit current at the point at which the device is installed. However a lower breaking capacity is permitted provided that a properly co-ordinated back-up device having the necessary breaking capacity is installed on the supply side.

Positioning of Overcurrent Devices

Devices for the protection against overload and short-circuit must be placed at the point where a reduction occurs in the current-carrying capacity of the conductors. This reduction could be caused by a change in the environmental conditions as well as the more obvious change in the cross-sectional area of the cable.

There are of course exceptions to this general rule which relate to a very few special applications. These are set out in detail in the Wiring Regulations.

Both of the new International Standards covering Low Voltage Circuit Breakers provide the user with a better assurance of quality and performance by taking into account the actual operating conditions of the breaker. New definitions and symbols have been introduced which should be committed to memory. Some of those most frequently used are:

- U_e : rated service voltage
- U_i : rated insulation voltage ($> U_{emax}$)
- U_{imp} : rated impulse withstand
- I_{cm} : rated short circuit making capacity
- I_{cn} : rated short circuit capacity
- I_{cs} : rated service short circuit breaking capacity
- I_{cu} : rated ultimate short circuit breaking capacity
- $I_{\Delta n}$: rated residual operating current (often called residual sensitivity)
- I_n : rated current = maximum value of current used for the temperature rise test
- Δt : trip delay of residual current devices

In addition IEC 898 sets out to provide a greater degree of safety to the uninstructed users of circuit breakers. It is interesting to note that the description "miniature circuit breaker" or MCB is not used at all in this standard, but no doubt both manufacturers and users will continue to call circuit breakers complying with IEC 898 miniature circuit breakers or MCBs for some time to come.

The scope of this standard is limited to ac air break circuit breakers for operation at 50Hz or 60Hz, having a rated current not exceeding 125A and a rated short-circuit capacity not exceeding 25kA.

A rated service short-circuit breaking capacity I_{cs} is also included which is equal to the rated short-circuit capacity I_{cn} for short-circuit capacity values up to and including 6kA, and 50% of I_{cn} above 6kA with a minimum value of 7.5kA. As the circuit- breakers covered by this standard are intended for household and similar uses, I_{cs} is of academic interest only. The rated short-circuit capacity of a MCB (I_{cn}) is the alternating component of the prospective current expressed by its r.m.s. value, which the MCB is designed to make, carry for its opening time and to break under specified conditions. I_{cn} is shown on the MCB label in a rectangular box without the suffix 'A' and is the value which is used for application purposes. I_{cn} (of the MCB) should be equal to or greater than the prospective short-circuit current at the point of application.

You will see from the curves that the inverse time delay characteristic which provides overload protection is the same on all three. This is because the Standards requires the breaker to carry 1.13 times the rated current without tripping for at least one hour and when the test current is increased to 1.45 times the rated current, it must trip within one hour, and again from cold if the last current is increased to 2.55 times the rated current the breaker must trip between 1 and 120 seconds. The inverse time delay characteristic of all MCBs claiming compliance with IEC 898 must operate within these limits.

The difference between the three types of characteristic curves designated 'B', 'C' and 'D' concerns only the magnetic instantaneous trip which provides short-circuit protection.

- For type 'B' the breaker must trip between the limits of 3 to 5 times rated current
- For type 'C' the breaker must trip between the limits of 5 to 10 times rated current, and
- For type 'D' the breaker must trip between the limits of 10 to 20 times rated current.

Often manufacturers publish their MCB tripping characteristics showing the limits set by the standard and guarantee that any breaker that you purchase will operate within these limits. So great care should be taken when working with characteristic curves showing lower and higher limits - on no account should you take a mean point for application design purposes.

For cable protection applications you should take the maximum tripping time and some manufacturers publish single line characteristic curves which show the maximum tripping time. If the design problem is nuisance tripping then the minimum tripping time should be used and for desk top co-ordination studies, both lower and upper limits have to be taken into account.

Energy limiting

Energy is measured in Joules. *James Prescott Joule proved that thermal energy was produced when an electric current flowed through a resistance for a certain time, giving us the formula :-

Joules = $I^2 \times R \times t$ or because we know that watts = $I^2 R$
 Joules = watts x seconds
 Therefore we can say that :-
 One Joule = one watt second
 or energy = watts x seconds = $I^2 R t$

If the resistance (R) remains constant or is very small compared with the current (I) as in the case of short-circuit current, then energy becomes proportional to $I^2 t$. Which is why the energy let-through of a protective device is expressed in ampere squared seconds and referred to as $I^2 t$

$I^2 t$ (Joule Integral) is the integral of the square of the current over a given time interval (t_0, t_1)

The $I^2 t$ characteristic of a circuit breaker is shown as a curve giving the maximum values of $I^2 t$ as a function of the prospective current.

Manufacturers are required by the Standard to produce the $I^2 t$ characteristic of their circuit breakers.
See page 39.

The energy limiting characteristics of modern MCBs greatly reduce the damage that might otherwise be caused by short-circuits. They protect the cable insulation and reduce the risk of fire and other damage. Knowledge of the energy limiting characteristic of a circuit breaker also helps the circuit designer calculate discrimination with other protective devices in the same circuit.

Because of the importance of the energy limiting characteristic the Standards for circuit breakers for household and similar installations suggests three energy limiting classes based on the permissible $I^2 t$ (let-through) values for circuit breakers up to 32A; class 3 having the highest energy limiting performance.

All Hager MCBs are well within the limits of energy let-through set by IEC 898 for energy limiting class 3.

Electrical characteristics	References												
	MJ	ML	MV	MW	MT	MU	MB	MC	NC	ND	NR	NM*	
Poles	SP+N	SP+N	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4	1,2,3,4
Rated operational voltage U_e (V) **	230	230	230/400	230/400	230/400	230/400	230/400	230/400	230/400	230/400	230/400	230/400	230/400
Nominal current	2-40A	6-40A	6-40A	6-40A	6-63A	6-63A	0.5-63A	0.5-63A	0.5-63A	0.5-63A	0.5-63A	0.5-63A	80-100A
Breaking capacity to IEC 898	4.5kA	6kA	3kA	3kA	6kA	6kA	6kA	6kA	6kA	10kA	10kA	-	-
Breaking capacity to IEC 947-2	-	-	-	-	10kA	10kA	10kA	10kA	15kA	15kA	25/20/15kA	10kA	
Rated insulation voltage U_i (V)	500V	500V	500V	500V	500V	500V	500V	500V	500V	500V	500V	500V	500V
Rated impulse voltage U_{imp} (kV)	2500V	2500V	2500V	2500V	2500V	2500V	2500V	2500V	2500V	2500V	2500V	2500V	2500V
Electrical endurance	10000	10000	20000	20000	20000	20000	20000	20000	20000	20000	20000	20000	20000

* din rail mount only, not for use in fixed busbar distribution boards.

** As per IEC38. Can be installed in 240/415V system without derating. Voltage tolerances -20% to +10%

Power loss

The power loss of MCB's is closely controlled by the standards and is calculated on the basis of the voltage drop across the main terminals measured at rated current. The power loss of Hager circuit breakers is very much lower than that required by the Standard, so in consequences run cooler and are less affected when mounted together.

The table below gives the watts loss per pole at rated current.

MCB rated current (A)	0.5	1	2	3	4	6	10	16	20	25	32	40	50	63	80	100
Watts loss per pole (W)	1.3	1.5	1.7	2.1	2.4	2.7	1.8	2.6	2.8	3.3	3.9	4.3	4.8	5.2	8	10

For use with DC

Because of their quick make and break design and excellent arc quenching capabilities Hager circuit breakers are suitable for DC applications.

The following parameters must be considered.

- system voltage:
Determined by the number of poles connected in series
- short circuit current:
- tripping characteristics:
 - the thermal trip remains unchanged
 - the magnetic trip will become less sensitive requiring derating by $\sqrt{2}$ the ac value.

No. of poles 1 pole

Range	1 pole		2 poles in series	
	Max voltage	Breaking capacity L/R=15ms	Max voltage	Breaking capacity L/R=15ms
MT, MU, MB, MC	60V	6kA	125V	6kA
NC, ND	60V	10kA	125V	10kA

Characteristic curve

Magnetic trip	B		C	
	50Hz	dc	50Hz	dc
I _{rm1}	3I _n	4.5 I _n	5I _n	7.5 I _n
I _{rm2}	5I _n	7.5 I _n	10I _n	15I _n

Note : the circuit breaker can have the line/load connected to either the top or bottom terminals

Temperature Derating

MCBs are designed and calibrated to carry their rated current and to operate within their designated thermal time/current zone at 40°C. Testing is carried out with the breaker mounted singly in a vertical plane in a controlled environment. Therefore if the circuit breaker is required to operate in conditions which differ from the reference conditions, certain factors have to be applied to the standard data. For instance if the circuit breaker is required to operate in a higher ambient temperature than 40°C it will require progressively less current to trip within the designated time/current zone.

correction factor

The breaker is calibrated at a temperature of 40°C.

Temperature correction

In (A)	45°C	50°C	55°C	60°C
0.5	0.48	0.46	-	-
1	0.96	0.92	0.88	0.84
2	1.92	1.84	1.76	1.68
3	2.88	2.76	2.64	2.9
4	3.3	3	2.8	2.52
6	5.76	5.52	5.28	5.04
10	9.6	9.2	8.8	8.4
16	15.4	14.7	14.1	13.4
20	19.2	18.4	17.6	16.8
25	24	23	22	21
32	30.7	29.4	28.2	26.9
40	38.4	36.8	35.2	33.6
50	48	46	44	42
63	60.5	58.0	55.4	52.9
80	76.8	73.6	70.4	67.2
100	96	92	88	84

Grouping factors

Consideration should also be given to the proximity heating effect of the breakers themselves when fully loaded and mounted together in groups. There is a certain amount of watts loss from each breaker depending on the trip rating which may well elevate the ambient air temperature of the breaker above the ambient air temperature of the enclosure.

grouping factor (rated current reduce by factor K)

No. of units n	K
n = 1	1
2 ≤ n < 4	0.95
4 ≤ n < 6	0.9
6 ≤ n	0.85

Frequency


thermal – unchanged

magnetic – value multiplied by coefficient K

F (Hz)	17Hz – 60Hz	100Hz	200Hz	400Hz
K	1	1.1	1.2	1.5


'B' curve (IEC 898)

MCBs: MT rated 6 - 63A
MV rated 6 - 40A
MB rated 0.5 - 63A




'C' curve (IEC 898)

MCBs : NC rated 0.5 - 63A MW rated 6-40A
MJ rated 2 - 40A MU rated 6-63A
NM rated 80 - 125A MC rated 0.5-63A
ML rated 6 - 40A




'D' curve (IEC 898)

MCBs: ND rated 1 – 100A




current limiting at 400V

MT, MB, MC, MU, MV, MW, NC, ND, NR




NM 80 - 100A




I²t characteristics


MW, MU, MC, NC, NR



MV, MT, MB



NM 80 - 100A



Functions

Tripping and indication auxiliary contacts are common to the range of multi-pole MCBs. They should be mounted on the left hand side of the device.

Auxiliary contact MZ 201

Allows remote indication of the status of the device contacts to which it is associated.

Alarm contact MZ 202

The alarm contact will provide indication if the breaker trips under fault conditions.

Shunt trip MZ 203 - MZ 204

Allows tripping of the device by feeding the coil. It is fitted with internal contacts which allow it to be fed by an impulse or latched feed.

MZ 203 - 230V to 415V ac / 110V to 130V dc

MZ 204 - 24V to 48V ac / 12 to 48V dc

Under voltage release MZ 205 - MZ 206


Allows the MCB to trip when the voltage drops or by pressing a remote off switch (ie emergency stop).

MZ 205 - 48V dc


MZ 206 - 230V ac

Wiring diagram

MZ 201 auxiliary contact




MZ 206 under voltage release



Electrical characteristics	MZ 201	MZ 202	MZ 203	MZ 204	MZ 205	MZ 206
Contact	1NO+1NC	1NO+1NC	-	-	-	-
Rating of contact	6A 230V AC	6A 230V AC	-	-	-	-
Coil voltage Un	-	-	230 to 415V AC 110 to 130V DC	24 to 48V AC 12 to 48V DC	48V DC	230V AC
Energising power	-	-	8VA	8VA	-	-
Voltage tolerances	-	-	-15% of Un	-15% of Un	-	-
Undervoltage	-	-	-	-	0.35 to 0.7Un	0.35 to 0.7Un

Mounting of auxiliaries



No tools is necessary for the mounting of the auxiliaries. The auxiliaries click onto the left side of the breakers and are held in place with special designed fixing points. The whole operation is performed within seconds. It is possible to fit the auxiliary without removing the associated device from the din rail.



Combination of auxiliaries with circuit breakers and RCCDs

It is possible to combine 4 auxiliaries with miniature circuit breakers, however the following must be observed :

- only one protection auxiliary is allowed.
- the trip contact MZ 202 must be mounted first.
- all auxiliaries are left mounted.



Transformer Protection

When a transformer is switched on, a high inrush current occurs in the primary circuit of the transformer irrespective of the load on the secondary side. Correct selection of the primary circuit protective device will avoid the risk of nuisance tripping due to this inrush current. Tables below show the recommended MCB's for the protection of single phase (230V) and three phase (400V) transformers.

Single Phase 230V

Transformer Rating (VA)	Primary Current (A)	Recommended MCB	
		NC	ND
50	0.22	1	6
100	0.43	2	6
200	0.87	3	6
250	1.09	4	6
300	1.30	4	6
400	1.74	6	6
500	2.17	10	6
750	3.26	10	6
1 000	4.35	16	10
2 500	10.87	40	20
5 000	21.74	63	32
7 500	32.60		50
10 000	43.48		63

Three Phase 400V

Transformer Rating (VA)	Primary Current (A)	Recommended MCB	
		NC	ND
500	0.72	3	6
750	1.08	4	6
1000	1.44	6	6
2000	2.88	10	6
3000	4.33	16	10
4000	5.77	20	10
5000	7.21	25	16
7500	10.82	32	20
10000	14.43	50	25
15000	21.64	63	32
20000	28.86		50
25000	36.07		63

Lighting circuits

Although the MCBs prime function is the protection of lighting circuits, they are often used as local control switches as well, conveniently switching on and off large groups of luminaries in shops and factories. The MCB is well able to perform this additional task safely and effectively. Hager MCBs have an electrical endurance of 20,000 on/off operations for rated trips up to and including 32A and 10,000 on/off operations for 40, 50 and 63A rated trips.

For the protection of lighting circuits the designer must select the circuit breaker with the lowest instantaneous trip current compatible with the inrush currents likely to develop in the circuit.

High Frequency (HF) ballasts are often singled out for their high inrush currents but they do not differ widely from the conventional 50Hz. The highest value is reached when the ballast is switched on at the moment the mains sine wave passes through zero. However, because the HF system is a "rapid start" system whereby all lamps start at the same time, the total inrush current of an HF system exceeds the usual values of a conventional 50Hz system. Therefore where multiple ballasts are used in lighting schemes, the peak current increases proportionally.

Mains circuit impedance will reduce the peak current but will not affect the pulse time.

The problem facing the installation designer in selecting the correct circuit breaker is that the surge characteristic of HF ballasts vary from manufacturer to manufacturer. Some may be as low as 12A with a pulse time of 3mS and some as high as 35A with a pulse time of 1mS. Therefore it is important to obtain the expected inrush current of the equipment from the manufacturer in order to find out how many HF ballasts can safely be supplied from one circuit breaker without the risk of nuisance tripping.

This information can then be divided into the minimum peak tripping current of the circuit breaker, shown in Table below

Minimum peak tripping current

Circuit breaker type	Circuit breaker rated current								
	6A	10A	16A	20A	25A	32A	40A	50A	63A
B	26	43	68	85	106	136	170	212	268
C	43	71	113	142	177	223	283	354	446
D	85	142	226	283	354	453	566	707	891



Example:

How many HF ballasts, each having an expected inrush of 20A can be supplied by a 16A type C circuit breaker? From table above, 16A type C we have a minimum peak tripping current of 113A.



Therefore $\frac{113}{20} = 5$

i.e. 5 ballasts can be supplied by a 16A type C circuit breaker.


Assembly of the RCCB add-on blocks ≤ 63 A




Assembly of the add-on blocks 80 - 100 A



Dimensions of associated MCB / RCCB add-on block



RCCB add-on blocks 25, 40 et 63 A





RCCB add-on blocks 80-100 A

	E
2 P.P. 6 to 63 A	4
2 P.P. 80 to 100 A	5,5
3 P.P. 6 to 25 A	5
3 P.P. 32 to 63 A	6
3 P.P. 80 to 100 A	9
4 P.P. 6 to 25 A	6
4 P.P. 32 to 63 A	7
4 P.P. 80 to 100 A	10,5

Wiring diagram for MCB+Add-on block from 25 to 100A

incoming



Test

Connection capacities :

- for assembled products from 6 to 25A : 6² / 10²
- for assembled products from 32 to 63 A : 10² / 25²
- for assembled products from 80 to 100A : 35² / 50²

If the supply of the RCCB add-on block is done from the bottom it should be clearly indicated.

Correction chart for admissible current

A - ambient temperature effect.
B - mutual temperature effect.

In conditions where both conditions are combined (ambient temperature > 20°C and 3 juxtaposed phases simultaneously on load) both coefficients A and B are applicable.

Type	L 31	L 38	L 51	L 58
fuse size	8.5x31.5	10,3 x 38	14 x 51	22 x 58
In for Un 400 V~	20A	32 A	50 A	125 A
In for Un 500 V~	16A	20 A	40 A	80 A
A	20°	1	1	1
	30°	0.95	0,95	0,95
	40°	0.9	0,90	0,90
	50°	0.8	0,80	0,80
B	1 to 3 Ph	1	1	1
	4 to 6 Ph	0.8	0,8	0,8
	7 to 9 Ph	0.7	0,7	0,7
	> 10 Ph	0.6	0,6	0,6


Function of auxiliary contact

- possible to disconnect the supply to the motor by wiring the auxiliary to the coil of the contactor.
- remote indication of the fuse blown status by wiring the auxiliary to an indicating lamp

Note :


to use the auxiliary for remote indication it is necessary to use fuse links with striker pins.

Indicating light mounting on L 51 and L 58




Auxiliary changeover contact


Identical mounting on L 51 and L 58 - SP and multipole type LS



Application drawing



Isolation and padlocking in open position



Residual current devices

A residual current device (RCCBS) is the generic term for a device which simultaneously performs the functions of detection of the residual current, comparison of this value with the rated residual operating value and opening the protected circuit when the residual current exceeds this value.

For fixed domestic installations and similar applications we have two types :-

- Residual current operated circuit-breaker without integral over-current protection (RCCB's) which should comply with the requirements of IEC 1008
- Residual current operated circuit-breaker with integral overcurrent protection (RCBO's) which should comply with the requirements of IEC 1009

Both RCCB's and RCBO's are further divided into types depending on their operating function :

Type AC For which tripping is ensured for residual sinusoidal alternating currents, whether suddenly applied or slowly rising. Marked with the symbol.



Type A For which tripping is ensured for residual sinusoidal alternating currents and residual pulsating direct currents, whether suddenly applied or slowly rising . Marked with the symbol.



Type S For selectivity, with time-delay. Marked with the symbol.



RCCB's must be protected against short-circuits by means of circuit-breakers or fuses

RCBO's have their own in built short-circuit protection, up to it's rated value

The drawing opposite shows how a torroid is located around the line and neutral conductors to measure the magnetic fields created by the current flowing in these conductors. The sum of the magnetic fields set up by these currents (which takes into consideration both the magnitude and phase relationship of the currents) is detected by the torroid.

In a normal healthy circuit the vector sum of the current values added together will be zero. Current flowing to earth, due to a line earth fault, will return via the earth conductor, and regardless of load conditions will register as a fault. This current flow will give rise to a residual current (Ires) which will be detected by the device.

It is most important that the line and neutral conductors are passed through the torroid. A common cause of nuisance operation is the failure to connect the neutral through the device.

RCCBSs work just as well on three phase or three phase and neutral circuits, but when the neutral is distributed it must pass through the torroid.

RCCBs are not suitable for use on DC systems and unearthed networks.


RCCBSs – domestic installation

RCCBs can be installed in two ways:

1. whole house protection.
2. selective protection.

Whole house protection is provided typically by a consumer unit where the RCCBs device serves as the main switch. Although very popular this suffers from a disadvantage: all circuits are disconnected in the event of fault. Selective protection can be provided by associating the RCCBs with identified high risk circuits by adopting one or more of the following :

Principle



Current flowing through torroid in healthy circuit

$$I_{res} = I_1 + I_2 = 0$$

Current flowing through torroid in circuit with earth fault I3

$$I_{res} = I_1 + I_2 + I_3 = I_3$$

- Split busbar consumer unit: All circuits are fed via an overall isolator and selected circuits fed additionally via the RCCBs. Typical circuits fed direct are lighting, freezer, storage heating; and circuits fed via the RCCBs are socket outlets, garage circuits. This concept minimises inconvenience in the event of fault.
- Whole ring circuit: A 30mA device adjacent to the consumer unit, which provides protection for the downstairs ring circuit, provides an easy installation with protection for all associated socket outlets. This represents the best solution for upgrading existing installations.

Nuisance tripping

All Hager RCCBs incorporate a filtering device preventing the risk of nuisance tripping due to transient voltages (lightning, line disturbances on other equipment...) and transient currents (from high capacitive circuit).

Pulsating DC fault current sensitive

Increasingly, semi-conductors are also extensively used in computers, VDUs, printers, plotters... all of which may be fed from the mains electrical supply. The presence of semi-conductors may result in the normal sinusoidal AC waveform being modified. For example, the waveform may be rectified or, as in asymmetric phase control devices, the waveform may be chopped. The resulting waveforms are said to have a pulsating DC component.

In the event of an earth fault occurring in equipment containing semi-conductor devices, there is a probability that the earth fault current will contain a pulsating DC component.

Standard type AC may not respond to this type of earth fault current and the intended degree of protection will not be provided.

Use of RCCBs

RCCBs offer excellent protection against earth fault currents; the main areas of application being as follows:

- **Zs value too high to allow disconnection in the required time**

Where the overcurrent protection or a circuit breaker cannot provide disconnection within the specified time because the earth fault loop impedance is too high the addition of RCCBs protection may well solve the problem without any other change in the system. Because of its high sensitivity to earth fault current and its rapid operating time, in most cases the RCCBs will ensure disconnection within the specified time. This is achieved without any detriment to overcurrent discrimination because, unlike the situation in a fuse based system, the increased sensitivity is obtained without increasing sensitivity to overcurrent faults. Use of RCCBs in this way can be particularly useful for construction sites and bathrooms where disconnection times are more stringent than for standard installations. (Construction sites - 0.2s at 220-277V, bathrooms - 0.4s).

The limitation to this technique is the requirement that the rated residual operating current multiplied by Zs should not exceed 50V. This is to avoid the danger of exposed conductive parts reaching an unacceptably high voltage level.

Residual current protection can even be added to a completed distribution system where the value of Zs is excessive, either because of a design oversight or subsequent wiring modification.

- **Protection against shock by direct contact**

So far we have considered shock by indirect contact only. Direct contact is defined thus:

Direct contact - contact of persons or livestock with live parts which may result in electric shock. The consideration here is not the hazard of parts becoming live as a result of a fault but the possibility of touching circuit conductors which are intentionally live.

RCCBs, although affording good protection against the potentially lethal effects of electric shock, must not be used as the sole means of protection against shock by direct contact. The Electricity at Work Act recommends the use of RCCBs, "...danger may be reduced by the use of a residual current device but states that this should be "...considered as a second line of defence". The Wiring Regulations defines the other measures that should be taken i.e.


- insulation of live parts.
- barriers or enclosures.
- obstacles.
- placing live parts out of reach.

Additionally an RCCB used for this purpose should have:

- a sensitivity of 30mA
- an operating time not exceeding 40mS at a residual current of 150mA.

The specified sensitivity is based on research that has been carried out to estimate the effect various levels and duration of current can have on the human body. This experience is summarised in a graph shown in 'IEC 479-1: Effects of current passing through the human body'. A simplified version of this graph is shown. It shows that very small currents can be tolerated for reasonably long periods and moderate currents for very short periods. It can be seen, for instance, that 100mA for 100mS or 20mA for 500mS will not normally cause any harmful effect. 200mA for 200mS or 50mA for 500mS which are in Zone 3, would be more dangerous; and shock levels in Zone 4 carry a risk of lethal consequences.

The tripping characteristic for a 30mA RCCBs is also shown in the graph. It shows the level of current required to cause the RCCBs to trip, for example; 50mA will cause a trip but not 10mA. Comparing its characteristic with the various zones on the graph it can be seen that the 30mA RCCBs gives a very good measure of protection against the hazards associated with electric shock. Where a higher level of protection is required, for example in laboratories, 10mA devices are available.



IEC 479-1

Note :

Although RCCBs are extremely effective devices they must never be used as the only method of protection against electric shock. With or without RCCBs protection all electrical equipment should be kept in good condition and should never be worked on live.

• **Protection against shock outside the equipotential bonding zone**

Bonding conductors are used in an installation to maintain metallic parts, as near as possible, to the same potential as earth. Working with portable equipment outside this equipotential bonding zone, e.g. in the car park of a factory, introduces additional shock hazards. Socket outlets rated 32A or less 'which may be reasonably expected to supply portable equipment for use outdoors' should have at least one socket nominated for outdoor use. This socket should be equipped with RCCBs protection unless fed from an isolating transformer or similar device, or fed from a reduced voltage.

• **Protection in special situations**

The use of RCCBs is obligatory or recommended in the following situations:

- caravans: 30mA RCCBs should be used.
- TT systems.
- swimming pools: 30mA RCCBs for socket outlets in Zone B obligatory; recommended in Zone C.
- agricultural and horticultural: 30mA RCCBs for socket outlets and for the purpose of protection against fire, RCCBS ≤ 0.5A sensitivity.
- construction sites: 30mA RCCBs recommended.

• **Portable equipment**

With the exception mentioned above, where a socket is specifically designated for work outside the equipotential bonding zone, the Wiring Regulations demand the use of RCCBs to protect the users of portable equipment. It is widely recognised that their use has made a significant contribution to safety in the workplace and the home.

• **Protection against fire hazards**

The provisions in the Wiring Regulations for protection against shock by indirect contact ensure rapid disconnection under earth fault assuming the fault has negligible impedance. Under such conditions the fault current, as we have seen, is sufficiently great to cause the overcurrent protection device to quickly disconnect the fault. However high impedance faults can arise where the fault current is sufficient to cause considerable local heat without being high enough to cause tripping of the overcurrent protective device. The heat generated at the point of the fault may initiate a fire long before the fault has deteriorated into a low impedance connection to earth.

The provision of residual current protection throughout a system or in vulnerable parts of a system will greatly reduce the hazard of fire caused by such faults.

• **PEN conductors**

The use of RCCBSs with PEN conductors is prohibited. A PEN conductor is a single conductor combining the functions of neutral conductor and protective conductor. This being so, when the PEN conductor is taken through the torroid of an RCCBS, earth faults will go undetected because the return path for the earth fault current is included in the residual sum.

• **Auxiliary contacts**

A range of auxiliaries, alarm and shunt contacts are available for Hager RCCBs.


• **Supply entry**

Top or bottom feed.

CB/RCCBs co-ordination

RCCBs	Short circuit current capacity of the RCCBS only	With MCB's				
		MT	MU	MC	NC	ND
		6-63A	6-63A	0.5-63A	0.5-63A	1-63A
		B	C	C	C	D
2 poles						
16A	1500A	6kA	6kA	6kA	10kA	6kA
25A	1500A	6kA	6kA	6kA	10kA	6kA
40A	1500A	6kA	6kA	6kA	10kA	6kA
63A	1500A	6kA	6kA	6kA	10kA	6kA
80A	1500A	6kA	6kA	6kA	10kA	6kA
4 poles						
16A	1500A	6kA	6kA	6kA	6kA	4.5kA
25A	1500A	6kA	6kA	6kA	6kA	4.5kA
40A	1500A	6kA	6kA	6kA	6kA	4.5kA
63A	1500A	6kA	6kA	6kA	6kA	4.5kA
80A	1500A	6kA	6kA	6kA	6kA	4.5kA
100A	1500A	6kA	6kA	6kA	6kA	4.5kA

Product presentation




Contact positioning indicator

The mechanical indicator on the front of RCCB shows the physical position of the contacts.

- Red indication for closed contacts
- Green indication for open contacts

The green indication is the guarantee that the contacts are open and that the terminals are not live.

Positive contact indication




Trip indicator

The status of the RCCB can be visualised by the colour of the trip indicator in addition to the position of the operating lever.

- Grey indication for normal conditions (even when operating lever is in ON/OFF position)
- Yellow indication for tripped condition, operating lever in OFF position.

Similar condition exists when TEST button is pushed or RCCB is remotely tripped via protection auxiliaries.

Earth leakage fault indication




Mounting of auxiliaries


It is possible to mount two auxiliaries on RCCB.

- Auxiliary CZ 001 for ON/OFF status and TRIP indication is mounted first on the left hand side of the RCCB.
- Additional protection auxiliary MZ 203 to MZ 206 can be mounted besides CZ 001.

Auxiliaries association possibilities



CZ 001
(CA+SD)



MZ 203... + CZ 001
MZ 206 (CA+SD)


Technical specifications

	non adjustable earth leakage relays		adjustable earth leakage relays		
	HR 400	HR 402	HR 410	HR 420	HR 425
power supply voltage ~ 50/60 Hz	230 V ± 20%				
controlled main voltage ~ 50/60 Hz	50 to 700 V				
input power	3 VA		5 VA		5 VA
control output	inverter free of potential				
breaking capacity (standard output, positive security, pre-alarm 50%)	6 A / 250 V AC1				
sensitivity I Δ n	0,03 A	0,3 A	0 / 0,03 A / 0,1 A / 0,3 A / 0,5 A / 1 A / 3 A / 10 A		
tripping (± 20%)	instantaneous		instantaneous; delayed 0,1 s / 0,3 s / 0,4 s / 0,5 s / 1 s / 3 s		
memory	storage of default by "reset" button				
acceptable overload at torroid level	30 kA / 100 ms				
voltage of test and reset buttons	100 to 250 V				
max. length of test/reset connection	200 m				
max. length of torroid/relay connection	50 m maxi with twisted cables of 1,5 mm ² - 25m non twisted cable				
relay connect. : cage terminals	rigid	1,5 [□] to 4 [□]			
	flexible	1 [□] to 2,5 [□]			
connect. torroid	rigid	1,5 [□] to 4 [□]			
	flexible	1 [□] to 6 [□]			
operating temperature	-10 to +55 °C				
storage temperature	-25 to +70 °C				

main characteristics


- ① **"reset" button** : in case of tripping, output remains switched and return to normal position is obtained either :
 - by pressing the "reset" clear pushbutton
 - or cutting off the power supply
- ② **"test" button** : pressing the "test" button allows a fault simulation which operates the relay and the output contacts.
- ③ **fault signal LED** : switched on when a fault is detected, intermittent light when break in connection relay/core.
- ④ **power indicator** : indicates well working of product.
- ⑤ **I Δ n selector** : 0,03 / 0,1 / 0,3 / 0,5 / 1 / 3 / 10 A
- ⑥ **time delay selector Δt** : 0 / 0,1 / 0,3 / 0,4 / 0,5 / 1 / 3 s (± 20 %)
- ⑦ **standard output (1 OF)** : tripping at 85 % of I Δ n ± 15 % goes from 0 to 1 when :
 - failure of the torroid/core connection,
 - fault current in the monitored installation.
- ⑧ **positive safety outlet (1 OF)** :
 - switching to state 1 : by switching on of the power :
 - switching to state 0 : failure of the torroid/relay connection,
 - fault current in installation,
 - fault supply or fault on internal relay.
- ⑨ **safety output (1 F)** : contact closes at 50 % of I Δ n (± 15 %)
- ⑩ **remote test and reset**
- ⑪ **optical scale display** : indicates permanently the value of leakage current, 5 to 15 %, 15 to 30 %, 30 to 45 %, 45 to 60 % and 60 to 75 % de I Δ n.

Product presentation




sealable settings : a sealable cover prevents interference once the settings have been made.


Electrical connections




**Circular torroids:
HR 800**



HR 801 to HR 805




**Rectangular torroids :
HR 830, HR 831, HR 832**



Dimensions for circular and rectangular torroids

references	size (en mm)									
	A	A1	A2	B	C	D	E	F	G	H
HR 801	ø 35	-	-	92	86	43,5	74	17	32,5	5,5
HR 802	ø 70	-	-	115	118	60,5	97	17	32,5	5,5
HR 803	ø 105	-	-	158	162,5	84,5	140	15	32,5	5,5
HR 804	ø 140	-	-	202	203	103,5	178	21	32,5	7,5
HR 805	ø 210	-	-	290	295	150	265	23	32,5	7,5
HR 830	-	70	175	260	162	85	225	22	40	7,5
HR 831	-	115	305	400	225	116	360	25	48	8,5
HR 832	-	150	350	460	270	140	415	28	48	8,5

Opening rectangular torroids :



Dimensions for opening rectangular torroids

	A1	A2	B	C	D	E	F
HR 820	20	30	89	110	41	32	46
HR 821	50	80	114	145	50	32	46
HR 822	80	80	145	145	50	32	46
HR 823	80	121	145	185	50	32	46
HR 824	80	161	184	244	70	37	46

Torroids capacity

on copper cables ►

U 1000 R2V cable single pole







U 1000 R2V cable single pole

U 1000 R2V cable 2 poles

U 1000 R2V cable 4 poles

U 1000 R2V cable 4 pole partially stripped multipole

U 1000 R2V cable 2 pole partially stripped multipole





Ø torroid inside ▼

30	HR 800	4 x 16 [□]	2 x 50 [□]	35 [□]	35 [□]	35 [□]	50 [□]
35	HR 801	4 x 25 [□]	2 x 70 [□]	35 [□]	50 [□]	35 [□]	70 [□]
70	HR 802	4 x 185 [□]	2 x 400 [□] ou 4 x 150 [□]	35 [□]	240 [□]	35 [□]	300 [□]
105	HR 803	4 x 500 [□]	2 x 630 [□] ou 4 x 185 [□]	35 [□]	300 [□]	35 [□]	300 [□]
140	HR 804	4 x 630 [□]	2 x 630 [□] ou 4 x 240 [□]	35 [□]	300 [□]	35 [□]	300 [□]
210	HR 805	4 x 630 [□]	2 x 630 [□] ou 4 x 240 [□]	35 [□]	300 [□]	35 [□]	300 [□]
70 x 175	HR 830	4 x 630 [□]	2 x 630 [□] ou 4 x 240 [□]	35 [□]	300 [□]	35 [□]	300 [□]
115 x 305	HR 831	4 x 630 [□]	2 x 630 [□] ou 4 x 240 [□]	35 [□]	300 [□]	35 [□]	300 [□]
150 x 350	HR 832	4 x 630 [□]	2 x 630 [□] ou 4 x 240 [□]	35 [□]	300 [□]	35 [□]	300 [□]
20 x 30	HR 820	4 x 16 [□]	2 x 70 [□]	35 [□]	10 [□]	35 [□]	16 [□]
50 x 80	HR 821	4 x 240 [□]	2 x 630 [□] ou 4 x 185 [□]	35 [□]	120 [□]	35 [□]	150 [□]
80 x 80	HR 822	4 x 500 [□]	2 x 630 [□] ou 4 x 185 [□]	35 [□]	300 [□]	35 [□]	300 [□]
80 x 120	HR 823	4 x 630 [□]	2 x 630 [□] ou 4 x 240 [□]	35 [□]	300 [□]	35 [□]	300 [□]
80 x 160	HR 824	4 x 630 [□]	2 x 630 [□] ou 4 x 240 [□]	35 [□]	300 [□]	35 [□]	300 [□]

on copper cables ►

H07 V - U 1 pole


H07 V - U 1 pole



Ø torroid inside ▼

30	HR 800	4 x 35 [□]	2 x 70 [□]
35	HR 801	4 x 50 [□]	2 x 95 [□]
70	HR 802	4 x 240 [□]	2 x 400 [□] ou 4 x 185 [□]
105	HR 803	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
140	HR 804	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
210	HR 805	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
70 x 175	HR 830	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
115 x 305	HR 831	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
150 x 350	HR 832	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
20 x 30	HR 820	4 x 10 [□]	2 x 35 [□]
50 x 80	HR 821	4 x 185 [□]	2 x 240 [□]
80 x 80	HR 822	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
80 x 120	HR 823	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]
80 x 160	HR 824	4 x 400 [□]	2 x 400 [□] ou 4 x 240 [□]

Installation example



Some installation rules for SPDs

- General SPD protects the whole installation by flowing the lightning current out to the earth. Fitted in directly downstream the type S differential function or delayed for system TT and TN-S.
- The cable length L1 must be reduced to less than 0,5m
- The resistance of the earth connection must be weakest possible (approx. 10 Ω) and only one is requested by installation,
- SPDs SPN 208S and SPN 408S protect very sensitive devices of class I and class II.
- A cable length of at least 1m is requested between general and secondary SPD to ensure a minimum impedance in order to avoid the simultaneous bringing into conduction of both SPDs,
- SPDs SPN 504 and SPN 505 protect analog or digital telephone lines from very sensitive receivers.

N.b. : when SPD is fitted downstream of differential system, the system should preferably be selectif to avoid inopportune setting of.

Choice of disconnection device

The choosen device is an MCB

Selection chart for disconnection device according to the SPD type

general SPD	C1 (1)
SPN 265R SPN 465R	32 A curve C
SPN 140C SPN 240R - SPN 240D SPN 440R - SPN 440D	32 A curve C
SPN 215R - SPN 215D SPN 415R - SPN 415D	32 A curve C

(1) The breaking capacity of MCB must be choosen according to the short circuit intensity at the head of the installation and according to the number of poles (1,2 or 4)

Distressing of SPD

Successive discharging of current due to lightning reduces progressively the performance of SPD's, with the consequence of a possible short circuit for the installation.

For this reason, all our SPDs are fitted with an automatic thermic and dynamic disconnection device

LED on front indicates the good working of the device :


- for normal version :
green = OK red = replacement
- for version with reserve indicator :
green = OK yellow = caution red = replacement
- for version with electric LED for SPDs for fine protection
green = OK LED off = replacement

Warranty

Warranty can not be applied for SPDs as their life expectancy depends on the perturbation level absorbed to protect the electric installation.

SPDs with plug in cartridge

Presentation of 1 pole and multi pole SPDs :
 available in two versions :
 - base with an auxiliary contact and cartridges with reserve indicator
 - base without auxiliary contact and cartridges with end of life LED



Keying system for fitting of neutral and phase cartridge


Neutral plug in cartridges can not be fitted in slots for phase cartridges and visa versa

On the front of the cartridge, a mechanical LED indicates the state of SPD


with reserve indicator



end of life LED



Auxiliary contact for signalling transfert




auxiliary contact connection capacity	mini maxi	0,5 mm ² 1,5 mm ²
remote signalling voltage	nominal current	230 V~ 250 V ∴ 1 A 0,1 A

Connection diagrams

Single pole SPDs : SPN 140C
 protection only in common mode


IT / TN-C



Multi pole SPDs : SPN 215D ... SPN 465R

protection is assured in both common and differential modes without adding devices

TT / TN-S



Technical characteristics of single pole SPDs

references		SPA 212A SPA 412A
installation exposure level (risk)		very high
installation of SPDs		in parallel
nominal voltage Un frequency		230 V~ 50/60 Hz
Max. continuous operating voltage Uc		255 V
voltage protection level Up		2,5 kV
protection mode		common differential
shock current	limp	12,5 kA
disconnection value	Ifi	12,5 kA
resistance to short-circuit	Icc alone with associated protect* of max. 125 A in series or 315 A in parallel	12,5 kA 25 kA
working temperature		-40 à + 60 °C
end of life LED		yes
earthing systems		TT - TNS
max.connection capacity	flexible rigid	25 mm ² 35 mm ²
screw head		PZ3

références		SPN 140C
installation exposure level (risk)		medium
installation of SPDs		in parallel
nominal voltage Un frequency		230 V~ 50/60 Hz
Max. continuous operating voltage Uc		440 V
voltage protection level Up		2 kV
discharge current capacity 8/20 µs wave		nominal current In max. current I _{max} 15 kA 40 kA
degree of protection		IP 20
short circuit resistance Icc (MCB - curve C)		20 kA - 32 A
temperature	working storage	-20 à + 60°C -40 à +70°C
end of live LED		SPN 140C
reserve indicator + auxiliary contact		-
domestic building	collective/individual industrial/commercial	yes yes
earthing systems		IT, TN-C
max. connection capacity (Ph, N, E)	flexible rigid	25 mm ² 35 mm ²
screw head		PZ2



technical characteristics of multipole SPDs

references		SPN 265R-SPN 465R	SPN 240R, SPN 440R SPN 240D, SPN 440D	SPN 215R, SPN 415R SPN 215D, SPN 415D
installation exposure level (risk)		very high	medium	low
installation of SPDs		in parallel	in parallel	in parallel
nominal voltage Un frequency		230/400 V~ 50/60 Hz	230/400 V~ 50/60 Hz	230/400 V~ 50/60 Hz
Max. continuous operating voltage Uc between Phase / Neutral between Neutre / PE		255 V 275 V	255 V 275 V	255 V 275 V
protection mode	common differential	yes yes	yes yes	yes yes
voltage protection level Up		1,5 kV	1,2 kV	1,0 kV
discharge current capacity 8/20 µs wave	nominal current In maxial current I _{max}	20 kA 65 kA	15 kA 40 kA	5 kA 15 kA
degree of protection		IP 20		
short circuit resistance Icc	(MCB - curve C)	20 kA - 32 A	20 kA - 32 A	10 kA - 32 A
working temperature		-40°C à +60°C		
end of life LED		-	SPN 240D - SPN 440D	SPN 215D - SPN 415D
reserve indicator + auxiliary contact		SPN 265R - SPN 465R	SPN 240R - SPN 440R	SPN 215R - SPN 415R
domestic buildings	collective / individual industrial / commercial	yes yes		
earthing systems		TT TN - S	TT TN - S	TT TN - S
connection capacity (Ph, N, E)	flexible rigid	25 mm ² 35 mm ²		
screw head		PZ2		


Technical characteristics of secondary SPDs (fine protection)

references		SPN 208S	SPN 408S
installation exposure level (risk)		low	low
installation of SPDs		in parallel	in parallel
nominal voltage U_n		230 V~	230/400 V~
frequency		50/60 Hz	50/60 Hz
Max. continuous operating voltage U_c	between N / PE between Phase and Neutral	255 V 255 V	255 V 255 V
protection mode	common differential	yes yes	yes yes
voltage protection level U_p		1,0 kV	1,0 kV
discharge current capacity	nominal current I_n maximal current I_{max}	2 kA 8 kA	2 kA 8 kA
8/20 μ s wave			
degree of protection		IP 20	IP 20
short circuit resistance I_{cc} (with fuse or associated MCB)		6 kA - 32 A	6 kA - 32 A
temperature	working storage	-25°C à +40°C -25°C à +40°C	-25°C à +40°C -25°C à +40°C
well functioning indicator		green LED	green LED
domestic buildings	collective / individual industrial / commercial	yes yes	yes yes
earthing systems		TT, IT, TN - S	TT, IT, TN - S
connection capacity (Ph, N, E)	flexible min./max. rigid min./max.	2,5/6 mm ² 6/10 mm ²	2,5/6 mm ² 6/10 mm ²
screw head		PZ1	

SPDs SPN 208S and SPN 408S



Coordination : between main SPD and secondary level SPDs, this coordination allows to reduce the protection level U_p to ≤ 800 V




Technical characteristics of the SPDs for telephone line


references		SPN 504	SPN 505
surge protective device		digital line (Numéris, RNIS, ISDN...)	analog line
installation of SPDs		in series	in series
ingress protection		IP 10	IP 10
nominal voltage Un		5 V / 40 V	130 V
maximum continuous operating voltage Uc		7,5 V / 60 V	170 V
voltage protection level Up		600 V	600 v
voltage protection level		common mode differential mode	yes yes
series impedance		1,0 Ω	4,7 Ω
discharge current wave		In (total) In (line)	5 kA / 10 kA (RJ 45 / vis) 2,5 / 5 kA (RJ 45 / vis)
working temperature		-40°C + 60°C	-40°C + 60°C
connection		in out	screw / RJ 45 screw / RJ 45
connection capacity (Ph, N, T)		flexible min./max. rigid min./max.	0,08 mm ² 2,5 mm ²
applications		digital line ISDN, RNIS	analog line

Electrical connection

SPN 504




SPN 505



Electrical characteristics

- electrical supply : 230 V / 400 V~
- ambient temperature range : from -25 to +55 °C
- working life : 100 000 operations - categorie : AC3
- maximum : 40 operations / hour
- tropicalized : normale all climates (TC)
- connection capacity :
flexible wire : from 1 to 4[□] rigid wire : from 1,5 to 6[□]
- insulation voltage : 6000 V
- frequency : 40 - 60 Hz


Single phase connection diagram



Breaking capacity

	230 V	400 V	230/400 V + fuse gl
MM 501N	100 kA	100 kA	100 kA
MM 502N			
MM 503N			
MM 504N			
MM 505N			
MM 506N			
MM 507N			
MM 508N			
MM 509N			
MM 510N			
MM 511N	16 kA	16 kA	50 kA
MM 512N			
MM 513N			

tripping curve



Auxiliaries

● auxiliary contacts 1O + 1F : MZ 520N

230 V~ 3,5 A
400 V~ 2 A



● cauxiliary contacts 1 F : MZ 522N

230 - 400 V~ 1 A



● default signal contact 2 F : MZ 527N

change state on short-circuit (magnetic tripping)  13-14

change state on overload and short-circuit (magnetic and thermic tripping)  23-24

● release : MZ 523N

230 V~
de 0,7 à 1,1 Un



● under voltage release : MZ 528N 230 V~, MZ 529N 400 V~

maintain voltage 0,85 x Un
fall voltage 0,7 à 0,35 x Un



● waterproof enclosure IP 55 : MZ 521N

allows to control the motor starter via external rotary handle


● emergency stop button : MZ 530N

- synchronized

- synchronized unlocking by key : MZ 531N

allows the emergency stop of motors by tripping auxiliary connected to MCB . (MZ 523N - MZ 528N - MZ 529N)

Connection of auxiliaries (without tool)



AUSTRIA :

Hager Electro Ges. m. b. H.
Dieselgasse, 3
2333 Leopoldsdorf / AUSTRIA
Tel. (43) 02235 / 44600
Fax (43) 02235 / 44545

BELGIUM :

S.A. Hager Modulec N.V.
Boulevard Industriel 61
BRUXELLES 1070 / BELGIUM
Tel. (32) 2 529 47 11
Fax (32) 2 527 12 61

CZECH REPUBLIC :

Hager Electro s.r.o.
Podebradská 186/56
18066 Praha 9 - Hloubetin
CZECH REPUBLIC
Tel. (42) 02 66 10 73 08
Fax (42) 02 66 10 73 10

CYPRUS :

N.P. LANITIS LTD
106 Gladstonos Street
3032 LIMASSOL
CYPRUS
Tel. (357)-25 819030
Fax (357)-25 819075
e.mail : info@nplanitis.com

DENMARK :

ELPEFA A/S
Postbox 180
2670 GREVE / DENMARK
Tel. (45) 43 95 95 95
Fax (45) 43 95 95 90

ESTONIA :

Hager Süsteemid OÜ
Türi 10d
11313 TALLINN
Tél. +372 655 61 46
Fax +372 655 61 68

FINLAND :

URHO TUOMINEN Oy
Palopellonkatu 7 - PL 33
04250 KERAVA / FINLAND
Tel. (358) 9 274 6411
Fax (358) 9 274 641 41

FRANCE :

Hager Electro S.A.
132, Bld d'Europe
B.P. n° 3
67215 OBERNAI Cedex
FRANCE
Tel. (33) 03 88 49 50 50
Fax (33) 03 88 49 50 03

GERMANY :

Hager Electro GmbH
Im Hofgarten
66131 SAARBRÜCKEN
GERMANY
Tel. (49) 68 93 94 50
Fax (49) 68 93 94 53 76

Hager Electro GmbH

Zum Gunterstal
66440 BLIESKASTEL
GERMANY
Tel. (49) 68 42 94 50
Fax (49) 68 42 94 56 76

GREAT BRITAIN :

Hager Ltd
Hortonwood 50
TELFORD, Shropshire
TF1 4FT / U.K.
Tel. (44) 1952 - 677 899
Fax (44) 1952 - 670 271
<http://www.hagergroup.com.uk>

GREECE :

Hager Hellas
Iapetou Street 33
11364 ATHENS / GREECE
Tel. (30) 1 864 50 90
Fax (30) 1 865 09 56

HUNGARY :

Hager Kft
Aradi utca 16
1043 BUDAPEST
Tél. +361 36 95 689
Fax +361 36 93 601

ICELAND :

Johan RÖNNING Hf
Sundaborg 15
104 REYKJAVIK / ICELAND
Tel. (354) 5 20 08 00
Fax (354) 5 20 08 88

IRELAND :

Hager Nolan Ltd
Techna House
Terenure Road East
DUBLIN 6 / IRELAND
Tel. (353) 1 - 490 6611
Fax (353) 1 - 490 1274

ITALY :

Hager Lume S.p.A.
Via Battistotti Sassi n. 11
20133 MILANO / ITALY
Tel. (39) 02 70 10 74 40
Fax (39) 02 70 10 74 30

LATVIA :

SIA Hager Sistēmas
Bauskas 58
1004 RIGA
Tél. +371 780 86 80
Fax +371 780 86 81

LITHUANIA :

Hager Polo UAB
Laisves pr 77
2600 VILNIUS
Tél. +370 5 274 28 27
Fax +370 5 274 28 38

MALTA :

International Trading Co.
White House Buildings
Mountbatten Street
BLATA L-BAJDA / MALTA
Tel. (356) 21 2402 91
Fax (356) 21 2431 86
<http://www.itc-malta.com>

NETHERLANDS :

Hager Electro b.v.
Larenweg 36
5234 KA's Hertogenbosch
NETHERLANDS
Tel. (31) 73 6428 584
Fax (31) 73 6442 674

NORWAY :

Hager Systemer A/S.
Industriveien 8b
Postboks 391
1473 SKÅRER / NORWAY
Tel. (47) 67 97 50 11
Fax (47) 67 97 20 55

POLAND :

Hager Polo Sp.zo.o.
ul. Domaniewska 39A
02-672 WARSZAWA
Tél. +48 22 640 28 80
Fax +48 22 640 28 81

PORTUGAL :

Hager SEM SA
(Sistemas Electricos Modulares)
Estrada para Polima
Complexo Meramar
Armazem C
Abóboda
2775 PAREDE / PORTUGAL
Tél. (351) 21 445 84 50
Fax (351) 21 445 84 54

RUMANIA :

Hager Romania SRL
B-dul Preciziei 32, Sect. 6
cod 062204
BUCURESTI Romania
Tél. +40 21 434 09 37
Fax +40 21 434 16 60

SPAIN :

Hager Sistemas S.A.
Paratge Coll-Blanc s/n
Apartado 39
08430 LA ROCA DEL VALLES
SPAIN
Tel. (34) 902 42 2232
(34) 93 842 4730
Fax (34) 93 842 2132

SWEDEN :

Hager Elektro AB
Box 9040
400 91 GÖTEBORG / SWEDEN
Tel. (46) 31 706 39 00
Fax (46) 31 706 39 50

SWITZERLAND :

Hager Tehalit AG
Moosweg 8,
Postfach 431
8501 FRAUENFELD
SWITZERLAND
Tel. (41) 052 723 24 00
Fax (41) 052 723 24 05

AUSTRALIA

Hager B&R Ltd
Unit 14 Riverside Centre
148 James Ruse Drive
(cnr River Road West)
North Parramatta NSW 2150
AUSTRALIA
Tel. (61) 2 - 9687 0077
Fax (61) 2 - 9687 0011 or 22
<http://www.hagergroup.com.au>

BAHRAIN, KUWAIT, OMAN, QATAR, SAUDI ARABIA, U.A.E., IRAN, EGYPT, PAKISTAN, AFGHANISTAN, IRAK and INDIA

Hager Tehalit Systems
M.E. FZE
POB 61056
JEBEL ALI
DUBAI / U.A.E.
Tel. (971) 4 - 883 63 64
Fax (971) 4 - 883 79 93
e-mail : htsme@emirates.net.ae
<http://www.hagergroup.com.ae>

CHINA

Hager Beijing Office
N° 308, He Qiao Building
8A Guang Hua Road
Chaoyang District
100026 BEIJING / CHINA
Tel. (86) 10-6503 5170
Fax (86) 10-6503 5173

EGYPT

**M.B. for Engineering &
Contracting**
10, Omar Ebnel Khattab Street
Dokky, Giza
EGYPT
Tel. (20) 2-3375283/7490592
Fax (20) 2-7490592
e-mail : tbshalaby@link.net

ERITREA

Electrolight Pvt. Ltd.
PO Box 4642
ASMARA / ERITREA
Tel. (291) 1 121265
Fax (291) 1 126759
e-mail : elelight@gemel.com.er

GHANA

Grand Pacific Ltd.
PO Box 140
KORLE-BU
ACCRA / GHANA
Tel. (233) 21 667037, 665778
Fax (233) 21 670316
e-mail : gpacific@ucomgh.com

HONG KONG

Hager Electro Ltd
Suite 310 Chinachem Golden
Plaza
77 Mody Road
Tsimshatsui East, Kowloon
HONG KONG
Tel. (852) 2688.0228
and 0234
Fax (852) 2688.0336

JORDAN

Dasouki Trading Corp.
PO Box 815422
11180 AMMAN / JORDAN
Tel. (962) 6 465 27 11
Fax (962) 6 464 74 72
e-mail : dasouki@index.com.jo

LEBANON

Cesar Debbas & Fils
Imm. Debbas
Corniche El-Nahr
BEIRUT 2069 6810
LEBANON
Tel. (961) 1 44 27 40
Fax (961) 1 44 75 62
e-mail : cdf@debbas.com.lb

LYBIA

ALWAQAEA Co.
Saadum Street
MISURATA
LYBIA
Tel. (218) 51 613471
Fax (961) 51 612390

KENYA

Nabico Enterprises Ltd.
PO Box 39639, 00623
Kirinyaga Road
NAIROBI / KENYA
Tel. (254) 20 336445, 224088
Fax (254) 20 225952
e-mail : nabico@africaonline.co.ke

MALAYSIA

**Hager Engineering (M)
SDN BHD**
N° 12, Jalan 4/91A
Taman Shamelin Perkasa
Cheras
56100 KUALA LUMPUR /
MALAYSIA
Tel. (60) 3 - 983 33 53
Fax (60) 3 - 983 23 35
<http://www.hagergroup.com.my>

MAURITIUS

Simelec
116 Royal Road, G.R.N.W.
PO Box 739
Bell Village, PORT LOUIS
MAURITIUS
Tel. (230) 212 10 73
Fax (230) 212 87 62
e-mail : simelec@intnet.mu

SINGAPORE :

**Hager Electro Systems
PTE Ltd**
23, New Industrial Road
04/04 Century Industrial
Building
SINGAPORE 536209
Tel. (65) 383 1030
Fax (65) 383 0230
<http://www.hagergroup.com.sg>

SOUTH AFRICA

**Electromechanica
(Gauteng)**
9/11 Data Crescent, Ormonde Ext. 8
PO Box 38980
BOOYSENS 2016
SOUTH AFRICA
Tel. (27) 11 249 5000
Fax (27) 11 496 2779
<http://www.em.co.za>

Electromechanica (Cape Province)

44 Freeway Park
cnr Upper Camp & Berkley Rd.
PO Box 267
MAITLAND
SOUTH AFRICA
Tel. (27) 21 510 5030
Fax (27) 21 510 5050

Electromechanica (Kwazulu Natal)

17 Mc Donald Road
PO Box 17317
CONGELLA 4013
SOUTH AFRICA
Tel. (27) 31 205 1571
Fax (27) 31 205 1625

SYRIA

Constructions Electriques Hanino
PO Box 5236
Abbara Al - Hamra
ALEPPO / SYRIA
Tel. (963) 21 211 33 73
Fax (963) 21 211 33 76

OTHER COUNTRIES

Hager Electro S.A.S.
PO Box 3
67215 OBERNAI Cedex
FRANCE
Tel. (33) 3 88 49 50 50
Fax (33) 3 88 49 51 44
e-mail : hageroverseas@hager.fr

The success is in the system

hager group

Hager Electro S.A.S
132, boulevard d'Europe
B.P. 3
67215 Obernai cedex
France
Tel +33 (0)3 88 49 50 50
Fax +33 (0)3 88 49 51 44
e-mail : hageroverseas@hager.fr
<http://www.hager.com>